



YAMAHA

XV250W

OWNER'S MANUAL

3LV-28199-20

IDENTIFICATION NUMBERS RECORD


1. KEY IDENTIFICATION NUMBER

2. VEHICLE IDENTIFICATION NUMBER: (For Australia) FRAME SERIAL NUMBER: (Except for Australia)

3. ENGINE SERIAL NUMBER:

Your key identification number is stamped on your key as shown in the following illustration.

Record this number in the space provided for reference if you need a new key.



Record your vehicle identification number (or frame serial number) and engine serial number in the spaces provided to assist you in ordering spare parts from your Yamaha dealer or for reference in case your vehicle is stolen (See page 2-1)

A-001

XV250W

OWNER'S MANUAL

©1989 by Yamaha Motor Co., Ltd.

1st Edition, January 1989

**All rights reserved. Any reprinting or
unauthorized use without the written
permission of Yamaha Motor Co., Ltd.
is expressly prohibited.**

Printed in Japan

INTRODUCTION

Congratulations on your purchase of the Yamaha XV250W. This model is the result of Yamaha's vast experience in the production of fine sporting, touring, and pacesetting racing machines. It represents the high degree of craftsmanship and reliability that have made Yamaha a leader in these fields. This manual will give you an understanding of the operation, inspection, and basic maintenance of this motorcycle. If you have any questions about the operation or maintenance of your motorcycle, please consult a Yamaha dealer

NOTE: _____
Some data in this manual may become outdated due to future improvement on this model. If you have any questions about this manual or your motorcycle, please consult a Yamaha dealer.

**TECHNICAL PUBLICATIONS
SERVICE DIVISION
MOTORCYCLE GROUP
YAMAHA MOTOR CO., LTD.**

⚠ WARNING:

PLEASE READ THIS MANUAL CAREFULLY AND COMPLETELY BEFORE OPERATING THIS MOTORCYCLE.

Particularly important information is distinguished in this manual by the following notations.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

⚠ CAUTION:

A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle

⚠ WARNING:

A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle

U-000

NOTE:

This manual should be considered a permanent part of this motorcycle and should remain with it even if the motorcycle is subsequently sold.

! THINK OF YOUR SAFETY:

Both motorcycles and mopeds are fascinating vehicles which give a tremendous feeling of freedom to their riders. They must be correctly maintained at all times in order to ensure optimum performance. However, as a rider you must also ensure that your physical condition is good, and that you are not tired, in order that you too can optimise your vehicle control. Medicines, drugs and alcohol should not be combined with riding, especially alcohol which increases the individual's likelihood of taking risks. Alcohol is dangerous, even in small quantities: Correct protective riding gear is just as much a part of motorcycling safety as the safety belt is in the car; a good leather suit and gloves, sturdy boots and a good quality, properly fitting crash helmet are ideal. But beware: good protective clothing can result in the individual being lulled into a false sense of security. When this happens more risks are taken and speeds increase... this particularly applies in wet weather. The good motorcyclist therefore rides defensively and protectively in order to minimise risks.

CONTENTS

DESCRIPTION.. .. .	1-1	Fuel cock	3-6
MOTORCYCLE IDENTIFICATION	2-1	Starter lever (CHOKE)	3-7
Frame serial number		Steering lock	3-7
(Except for Australia)	2-1	Seat removal	3-8
Vehicle identification number		Helmet holder	3-9
(For Australia)	2-1	Rear shock absorber	3-9
Engine serial number	2-2	Sidestand	3-10
CONTROL FUNCTIONS	3-1	Sidestand/clutch switch operation	
Main switch	3-1	check... .. .	3-10
Indicator lights	3-2	PRE-OPERATION CHECKS.....	4-1
Speedometer	3-2	Brakes	4-3
Handlebar switches	3-3	Brake fluid leakage	4-3
Clutch lever	3-4	Clutch	4-4
Change pedal.. .. .	3-4	Throttle grip	4-4
Front brake lever	3-5	Engine oil..... .. .	4-4
Rear brake pedal	3-5	Chain	4-5
Fuel tank cap	3-5	Tires	4-5
		Wheels	4-7

Fittings/Fasteners	4-7	Carburator adjustment...	6-11
Lights and signals.	4-8	Idle speed adjustment....	6-11
Switches	4-8	Throttle cable adjustment...	6-12
Battery.....	4-8	Valve clearance adjustment	6-13
Fuel.....	4-8	Spark plug inspection...	6-13
		Front brake adjustment....	6-14
OPERATION AND IMPORTANT		Rear brake adjustment..	6-15
RIDING POINTS	5-1	Brake light switch adjustment.....	6-17
Starting and warming up		Checking the front brake pads	
a cold engine	5-1	and rear brake shoes.....	6-17
Starting a warm engine	5-4	Inspecting the brake fluid level	6-18
Shifting	5-4	Brake fluid replacement.....	6-19
Engine break-in	5-5	Clutch adjustment	6-20
Parking..	5-6	Free play adjustment	6-20
		Drive chain slack check.....	6-21
PERIODIC MAINTENANCE AND		Drive chain slack adjustment.	6-21
MINOR REPAIR	6-1	Drive chain lubrication	6-23
Tool kit	6-1	Cable inspection and lubrication . . .	6-24
Periodic maintenance/lubrication . . .	6-3	Throttle cable and grip lubrication ..	6-24
Torque specifications....	6-5	Brake and change pedals	6-24
Engine oil.....	6-6	Brake and clutch levers	6-24
Air filter	6-9	Sidestand	6-25

Front fork inspection	6-25
Rear shock absorber adjustment	6-26
Steering inspection	6-27
Wheel bearings	6-27
Battery	6-27
Replenishing the battery fluid	6-29
Fuse replacement	6-30
Replacing the headlight bulb	6-30
Headlight beam adjustment	6-32
Front wheel removal	6-32
Front wheel installation	6-33
Rear wheel removal	6-34
Rear wheel installation	6-36
Troubleshooting	6-37
Troubleshooting chart	6-38




CLEANING AND STORAGE	7-1
A. Cleaning	7-1
B. Storage	7-2

SPECIFICATIONS	8-1
----------------------	-----

NOISE REGULATION (FOR AUSTRALIA)	9-1
---	-----

WIRING DIAGRAM

DESCRIPTION



- | | |
|-----------------------|---------------------|
| 1 Tail/brake light | 11 Rear wheel |
| 2 Rear flasher light | 12 Main switch |
| 3 Seat | 13 Change pedal |
| 4 Air filter | 14 Front wheel |
| 5 Front flasher light | 15 Clutch lever |
| 6 Brake pedal | 16 Handlebar switch |
| 7 Footrest | 17 Speedometer |
| 8 Headlight | 18 Brake lever |
| 9 Fuel tank | 19 Throttle grip |
| 10 Helmet holder | |

U-002

NOTE:

The motorcycle you have purchased may differ slightly from those shown in the photographs

MOTORCYCLE IDENTIFICATION

A-602

Frame serial number (Except for Australia)

The frame serial number is stamped into the right side of the steering head pipe.


Vehicle identification number (For Australia)

The vehicle identification number is stamped into the steering head pipe.

U-004

NOTE: _____


The vehicle identification number is used to identify your motorcycle and may be used to register your motorcycle with the licensing authority in your state.



- 1 Frame serial number
- 1. Vehicle identification number

Engine serial number

The engine serial number is stamped into the left side of the engine.



1 Engine serial number

U-003

NOTE: _____

The first three digits of these numbers are for model identification, the remaining digits are the unit production number. Keep a record of these numbers for reference when ordering parts from a Yamaha dealer.


B-000

CONTROL FUNCTIONS

B-001

Main switch

The main switch controls the ignition and lighting systems, its operation is described below.



B-005

ON.

Electrical circuits are switched on. The engine can be started. The key cannot be removed in this position.

B-006

OFF.

All electrical circuits are switched off. The key can be removed in this position.

EAB02000

PARKING:

The taillight and auxiliary light come on but all other circuits are off. With the key at "OFF", push it into the main switch, turn it counterclockwise to "PARKING", and remove it. To cancel the parking, turn the key clockwise.


EUU08800

NOTE:

Always turn the main switch to "OFF" and remove the key when the motorcycle is unattended.

B-100

Indicator lights



- 1 "TURN" indicator light
- 2 "NEUTRAL" indicator light
- 3 "HIGH BEAM" indicator light

B-101

"TURN" indicator light (orange)

This indicator flashes when the turn switch is "ON"

B-102

"NEUTRAL" indicator light (green).

This indicator comes on when the transmission is in neutral

B-103

"HIGH BEAM" indicator light (blue).


This indicator comes on when the headlight high beam is used.

B-400

Speedometer

The odometer and trip odometer are built into the speedometer. The trip odometer can be reset to "0" with the reset switch.

Use the odometer to estimate how far you can ride on a tank of fuel before going to "RESERVE" This information will enable you to plan fuel stops in the future.




- 1 Odometer
- 2 Trip odometer

3-2 3 Reset switch

B-600

Handlebar switches:



- 1 "PASS" switch
- 2 "LIGHTS" (Dimmer) switch
- 3 "TURN" signal switch
- 4 "HORN" switch
- 5 "ENGINE STOP" switch
- 6 "LIGHTS" switch
- 7 "START" switch

B-610

"PASS" switch

When you are passing a vehicle ahead, the passing light switch should be depressed so that the headlight gives a signal to the rider

B-601

"LIGHTS" (Dimmer) switch

Turn the switch to "HI" for the high beam and to "LO" for the low beam.

B-603

"TURN" signal switch

This model is equipped with self-cancelling turn signals. To signal a right-hand turn, push the switch to the right; to signal a left-hand turn, push the switch to the left. Once the switch is released it will return to the center position. To cancel the signal, push the switch in after it has returned to the center position. If the switch is not cancelled by hand, it will self-cancel after the motorcycle has travelled for about 10 seconds or approximately 150 meters (490 feet) whichever is greater. The self-cancelling mechanism only operates when the motorcycle is moving; thus the signal will not self-cancel while you are stopped at an intersection.

B-602

“HORN” switch

Press the switch to sound the horn.

B-612

“LIGHTS” switch

Turn the light switch to “ON” to turn on the headlight, taillight, and meter lights. Turn the light switch to “PO” to turn on the auxiliary light, taillight, and meter lights.

B-609

“ENGINE STOP” switch

The engine stop switch is a safety device for use in an emergency such as when the motorcycle overturns or when trouble occurs in the throttle system. The engine will not run when the engine stop switch is turned to “OFF.” In case of emergency, turn the switch to “OFF.”

B-607

“START” switch

To start the engine, push the starter

U-307



See starting instructions prior to starting engine.

B-700


Clutch lever

The clutch lever is located on the left handlebar, and the starting circuit cut-off switch is incorporated in the clutch lever holder. Pull the clutch lever to the handlebar to disengage the clutch, and release the lever to engage the clutch. The lever should be pulled rapidly and released slowly for smooth starts. (Refer to the engine starting procedures for a description of the starting circuit cut-off switch.)

B-800

Change pedal

The gear ratios of the constant-mesh 5-speed transmission are ideally spaced. The gears can be shifted by using the change pedal on the left side of the engine.



1 Change pedal

N Neutral

B-900

Front brake lever

The front brake lever is located on the right handlebar. Pull it toward the handlebar to activate the front brake.

B-901

Rear brake pedal

The rear brake pedal is on the right side of the motorcycle. Press down on the brake pedal to activate the rear brake.

C-001

Fuel tank cap

TO OPEN:

Insert the key and turn clockwise 1/4 turn. The lock will be released and the cap can be opened.


TO CLOSE

Push the tank cap into position with the key inserted. To remove the key, turn it counter clockwise to the original position.

U-012

NOTE: _____

This tank cap cannot be closed unless the key is in the lock. The key cannot be removed if the cap is not locked properly.



1 Open

C-102

Fuel cock

The negative pressure fuel cock supplies fuel from the tank to the carburetors and also filters the fuel. The fuel cock has the following three positions.

ON With the lever in this position, fuel flows if the engine is running but stops if the engine is not running

RES. This indicates reserve. If you run out of fuel while riding, move the lever to


"PRI", start the engine, then switch to "RES" FILL THE TANK AT THE FIRST OPPORTUNITY. BE SURE TO SET THE LEVER TO "ON" AFTER REFUELING.

U-014

NOTE: _____

The fuel cock operates on vacuum from the engine when set at "ON" or "RES" If the line connecting the cock to the carburetor intake manifold is not connected or has a leak, the cock will not function properly

PRI: This indicates prime With the lever in this position, fuel flows whether the engine is running or not If the fuel tank is completely empty, refill the tank, prime the carburetor in this position, and then switch to "ON" after starting the engine



C-201

Starter lever (CHOKE)


The starter lever is located on the left handlebar.

Starting a cold engine requires a richer fuel mixture. In such a case, turn the starter lever to the left. After the engine is warm, turn the lever to its original position.

U-016

NOTE:

Refer to "Starting and warming up a cold engine" for proper operation



1 Starter lever (CHOKE)

C-302

Steering lock


To lock the steering, turn the handlebars all the way to the right, and insert the key into the steering lock. Turn the key 1/8 turn counterclockwise, push it in, then turn it 1/8 turn clockwise. After checking to see that the lock is engaged, remove the key from the lock. To release the lock, reverse the above procedure.



C-415

Seat removal

To remove the rider seat, remove the two bolts. When reinstalling the rider seat, insert the lob on the seat front into the receptacle on the frame, then tighten the bolts




Helmet holder

To open the helmet holder, insert the key in the lock and turn it as shown. To lock the helmet holder, replace the holder in its original position.

U-615

⚠ WARNING:

Never ride with a helmet in the helmet holder. It could interfere with rear wheel movement, causing loss of control and possibly an accident.




1 Helmet holder

2. Open

Rear shock absorber

The spring preload of the rear shock absorber can be adjusted to suit motorcycle's load (ex optional accessories etc.) and riding conditions. Refer to page 6-26 for proper adjustment procedures.



1. Softest

2 Stiffest

Sidestand

This model is equipped with an ignition circuit cut-off system. The motorcycle must not be ridden when the sidestand is down. The sidestand is located on the left side of the frame. (Refer to page 5-1 for an explanation of this system.)

U-689

⚠ WARNING:

This motorcycle must not be operated with the sidestand in the down position. If the stand is not properly retracted, it could contact the ground and distract the operator resulting in a possible loss of control. Yamaha has designed into this motorcycle a lockout system to assist the operator in fulfilling his responsibility of retracting the sidestand. Please check carefully the operating instructions listed below and if there is any indication of a mal-

function, you must return the motorcycle to a Yamaha dealer immediately for repair.

D-308

Sidestand/clutch switch operation check


Check the operation of the sidestand switch and clutch switch against the information below.

CD3-01

TURN MAIN SWITCH TO "ON" AND ENGINE STOP SWITCH TO "RUN"

TRANSMISSION IS IN GEAR AND SIDESTAND IS UP

PULL IN CLUTCH LEVER AND PUSH STARTER SWITCH



U-691

⚠ WARNING:

If improper operation is noted, consult a Yamaha dealer immediately.

PRE-OPERATION CHECKS

Before using this motorcycle, check the following points.

Item	Routine	Page
Front brakes	Check operation, free play, fluid level, and fluid leakage Top-up with DOT #4 (or #3) brake fluid if necessary	4-3 ~ 4-4, 6-14 ~ 6-20
Rear brake	Check operation, condition and free play Adjust if necessary	
Clutch	Check operation, condition and free play Adjust if necessary	4-4, 6-20
Throttle grip/Housing	Check for smooth operation Lubricate/Adjust if necessary	4-4, 6-12, 6-24
Engine oil	Check oil level/add oil as required	4-4, 6-6 ~ 6-8
Drive chain	Check chain slack and condition Adjust if necessary	4-5, 6-21 ~ 6-23
Wheels/Tires	Check tire pressure, wear, damage and spoketightness	4-5 ~ 4-7, 6-32 ~ 6-36
Control/Meter cables	Check for smooth operation Lubricate if necessary	6-24
Brake and change pedal shafts	Check for smooth operation Lubricate if necessary	6-24
Brake and clutch lever pivots	Check for smooth operation Lubricate if necessary	6-24
Sidestand pivot	Check for smooth operation. Lubricate if necessary	6-25
Fittings/fasteners	Check all chassis fittings and fasteners. Tighten/Adjust, if necessary	4-7, 6-5
Fuel tank	Check fuel level/top-up as required	4-8 ~ 4-9
Lights and signals	Check for proper operation	4-8, 6-30 ~ 6-32
Battery	Check fluid level, top-up with distilled water if necessary	4-8, 6-27 ~ 6-30

NOTE:

Pre-operation checks should be made each time the motorcycle is used. Such an inspection can be thoroughly accomplished in a very short time, and the added safety it assures is more than worth the time involved.

⚠ WARNING:

If any item in the Pre-Operation Check is not working properly, have it inspected and repaired before operating the motorcycle.

Brakes (See page 6-14 for more detail)

1. Brake lever and brake pedal

Check for correct free play in the front brake lever and rear brake pedal. Make sure they are working properly. Check the brakes at low speed shortly after starting out. If the free play is incorrect, adjust it.

⚠ WARNING:

A soft, spongy feeling in the brake lever indicates a failure in the brake system. Do not operate the motorcycle until the failure in the brake system is corrected. Ask a Yamaha dealer for immediate repairs. A soft, spongy feeling could indicate a hazardous condition in the brake system.

2. Brake fluid

Check the brake fluid level.
Add fluid if necessary.

Recommended brake fluid. DOT#4

NOTE:

If DOT#4 is not available #3 can be used.

3. Check the disc pads

Refer to page 6-17.

4. Check the brake shoes

Refer to page 6-17.

NOTE:

When this brake service is necessary, ask a Yamaha dealer.

Brake fluid leakage (Front)

Apply the brake for a few minutes. Check to see if any brake fluid leaks out from the pipe joints or the master cylinder.

⚠ WARNING:

If brake fluid leakage is found, ask a Yamaha dealer for immediate repairs. Such leakage could indicate a hazardous condition.

Clutch (See page 6-20 for more detail)


Check the free play in the clutch lever, and make sure the lever operates properly. If the free play is incorrect, adjust it.

Throttle grip (See page 6-12 for more detail)

Turn the throttle grip to see if it operates properly, and check the free play. Make sure the grip returns by spring force when released. Ask a Yamaha dealer to make any necessary adjustments.

Engine oil (See page 6-6 for more detail)

Make sure the engine oil is at the specified level. Add oil as necessary.

Recommended oil.**Oil quantity:**

Total amount:

1.8 L (1.6 Imp qt, 1.9 US qt)

Periodic oil change:

1.4 L (1.2 Imp qt, 1.5 US qt)

With oil filter replacement:

1.6 L (1.4 Imp qt, 1.7 US qt)

NOTE:

Recommended engine oil classification, API Service "SE", "SF" type or equivalent (e.g. "SF-SE", "SF-SE-CC", "SF-SE-SD" etc.).

Chain (See page 6-21 for more detail)

Check the general condition of the chain and check the chain slack before every ride. Lubricate and adjust the chain as necessary

Tires

To ensure maximum performance, long service, and safe operation, note the following:

1 Tire air pressure

Always check and adjust the tire pressure before operating the motorcycle

⚠ WARNING:

Tire inflation pressure should be checked and adjusted when the temperature of the tire equals the ambient air temperature. Tire inflation pressure must be adjusted according to total weight of cargo, rider, passenger, and accessories (fairing, saddlebags, etc. if approved for this model), and vehicle speed.

Basic weight With oil and full fuel tank	147 kg (324 lb)	
Maximum load*	183 kg (403 lb)	
Cold tire pressure	Front	Rear
Up to 90 kg (180 lb) load*	180 kPa (1.8 kg/cm ² , 26 psi)	200 kPa (2.0 kg/cm ² , 28 psi)
90 kg (198 lb) ~ Maximum load*	200 kPa (2.0 kg/cm ² , 28 psi)	230 kPa (2.3 kg/cm ² , 33 psi)
High speed riding	200 kPa (2.0 kg/cm ² , 28 psi)	230 kPa (2.3 kg/cm ² , 33 psi)

* Load is the total weight of cargo, rider, passenger, and accessories


⚠ WARNING:

Proper loading of your motorcycle is important for the handling, braking, and other performance and safety characteristics of your motorcycle. Do not carry loosely packed items that can shift. Securely pack your heaviest items close to the center of the mo-

torcycle, and distribute the weight evenly from side to side. Properly adjust the suspension for your load, and check the condition and pressure of your tires. **NEVER OVERLOAD YOUR MOTORCYCLE.** Make sure the total weight of the cargo, rider, passenger, and accessories (fairing, saddlebags, etc. if approved for this model) does not exceed the maximum load of the motorcycle. Operation of an overloaded motorcycle could cause tire damage, an accident, or even injury.

2. Tire inspection

Always check the tires before operating the motorcycle. If a tire tread shows crosswise lines (minimum tread depth), if the tire has a nail or glass fragments in it, or if the side wall is cracked, contact a Yamaha dealer immediately and have the tire replaced.



1. Tread depth 2. Side wall 3. Wear indicator

CE9-02
FRONT

Manufacture	Size	Type
IRC	3 00-18-4PR	NF27

REAR

Manufacture	Size	Type
IRC	130/90-15 M/C 66P	NR31

Minimum tire tread depth (front and rear)	1 0 mm (0 04 in)
---	------------------

⚠ WARNING:

- 1. It is dangerous to ride with a worn-out tire. When a tire tread begins to show lines, have a Yamaha dealer replace the tire immediately. Brakes, tires, and related wheel parts replacement should be left to a Yamaha Service Technician.**
- 2. Patching a punctured tube is not recommended. If it is absolutely necessary to do so, use great care and replace the tube as soon as possible with a good quality replacement.**

E-934

Wheels

To ensure maximum performance, long service, and safe operation, note the following

- 1 Always inspect the wheels before a ride. Check for cracks, bends, or warpage of

the wheel, be sure the spokes are tight and undamaged. If any abnormal condition exists in a wheel, consult a Yamaha dealer. Do not attempt even small repairs to the wheel. If a wheel is deformed or cracked, it must be replaced.

- 2 Tires and wheels should be balanced whenever either one is changed or replaced. Failure to have a wheel balanced can result in poor performance, adverse handling characteristics, and shortened tire life.
- 3 After installing a tire, ride conservatively to allow the tire to seat itself on the rim properly. Failure to allow proper seating may cause tire failure, resulting in damage to the motorcycle and injury to the rider.

E-850

Fittings/Fasteners

Always check the tightness of chassis fittings and fasteners before a ride. Use the chart on page 6-5 to find the correct torque.

E-700

Lights and signals

Check the headlight, flasher lights, taillight, brake light, meter lights, and all the indicator lights to make sure they are in working condition

E-707

Switches

Check the operation of the headlight switch, turn switch, brake light switch, horn switch, starter switch, main switch, etc.

E-705

Battery (See page 6-27 for more detail)

Check the fluid level and top-up if necessary. Use only distilled water if refilling is necessary.

E-800


Fuel

Make sure there is sufficient fuel in the tank.

U-610

⚠ WARNING:

Do not overfill the fuel tank. Avoid spilling fuel on the hot engine. Do not fill the fuel tank above the bottom of the filler tube as shown in the illustration or it may overflow when the fuel heats up later and expands.



1 Filler tube

2 Fuel level

Recommended fuel: Regular gasoline

For Australia: Unleaded fuel only

Fuel tank capacity:

Total:

9.5 L (2.1 Imp gal, 2.5 US gal)

Reserve:

2.6 L (0.6 Imp gal, 0.9 US gal)

OPERATION AND IMPORTANT RIDING POINTS

U-672

WARNING:

Before riding this motorcycle, become thoroughly familiar with all operating controls and their function. Consult a Yamaha dealer regarding any control or function that you do not thoroughly understand.

U-628

WARNING:

1. Never start your engine or let it run for any length of time in a closed area. The exhaust fumes are poisonous and can cause loss of consciousness and death within a short time. Always operate your motorcycle in an area with adequate ventilation.

2. Before starting out, always be sure the sidestand is up. Failure to retract the sidestand completely can result in a serious accident when you try to turn a corner.

F-156

Starting and warming up a cold engine

U-028

NOTE:


This motorcycle is equipped with a starting and an ignition circuit cut-off switch.

1. The engine can be started only under the following conditions:
 - a. The transmission is in neutral.
 - b. The sidestand is up, the transmission is in gear, and the clutch is disengaged
2. The motorcycle must not be ridden when the sidestand is down

⚠ WARNING:

Before going through the following steps, check the function of the sidestand switch and clutch switch. (Refer to page 3-10.)

CF1-01



1. Turn the fuel cock to "ON."
2. Turn the ignition key to "ON" and the engine stop switch to "RUN."
3. Shift transmission into neutral.

U-030

NOTE: _____

When the transmission is in neutral, the neutral indicator light (green) should be on. If the light does not come on, ask a Yamaha dealer to inspect it.

4. Fully open the starter (CHOKE) and completely close the throttle grip
5. Start the engine by pushing the starter switch.

U-025

NOTE: _____

If the engine fails to start, release the starter switch, wait a few seconds, then try again. Each attempt should be as short as possible to preserve the battery. Do not crank the

engine more than 10 seconds on any one attempt.

6. After starting the engine, turn back the starter (CHOKE) to warming up position (about halfway).

U-026

NOTE: _____

To get maximum engine life, always warm up the engine before starting off. Never accelerate hard with a cold engine!

7. After warming up the engine, turn off the starter completely.

U-027

NOTE: _____

The engine is warm when it responds normally to the throttle with the starter turned off.

Starting a warm engine

The starter (CHOKE) is not required when the engine is warm

CAUTION:

See "Break-in section" prior to operating the motorcycle for the first time.

Shifting

The transmission lets you control the amount of power you have available at a given speed for starting, accelerating, climbing hills, etc. The use of the change pedal is shown in the illustration. (Page 3-4)

To shift into NEUTRAL, depress the change pedal repeatedly until it reaches the end of its travel (you will feel a stop when you are in first gear) then raise the pedal slightly.

CAUTION:

1. Do not coast for long periods with the engine off, and do not tow the motorcycle a long distance. Even with gears in neutral, the transmission is only properly lubricated when the engine is running. Inadequate lubrication may damage the transmission.
 2. Always use the clutch when changing gears. The engine, transmission, and driveline are not designed to withstand the shock of forced shifting and can be damaged by shifting without the clutch.
-

Engine break-in

There is never a more important period in the life of your motorcycle than the period between zero and 1,000 km (600 mi). For this reason we ask that you carefully read the following material. Because the engine is brand new, you must not put an excessive load on it for the first 1,000 km (600 mi). The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full throttle operation or any condition which might result in excessive heating of the engine, must be avoided.

1. 0 ~ 150 km (0 ~ 90 mi):
Avoid operation above 1/3 throttle. Stop the engine and let it cool for 5 to 10 minutes after every hour of operation. Vary the speed of the motorcycle from time to time. Do not operate it at one set throttle position.

2. 150 ~ 500 km (90 ~ 300 mi):
Avoid prolonged operation above 1/2 throttle. Rev the motorcycle freely through the gears, but do not use full throttle at any time.
3. 500 ~ 1,000 km (300 ~ 600 mi):
Avoid cruising speeds in excess of 3/4 throttle.



After 1,000 km (600 mi) of operation, be sure to replace the engine oil and clean the oil filter element and oil strainer.

4. 1,000 km (600 mi) and beyond:
Avoid prolonged full-throttle operation. Vary speed occasionally.

⚠ CAUTION: _____

If any engine trouble should occur during the break-in period, consult a Yamaha dealer immediately.

Parking

When parking the motorcycle, stop the engine and remove the ignition key

⚠ WARNING: _____

The muffler and exhaust pipe are hot. Park the motorcycle in a place where pedestrians or children are not likely to touch the motorcycle.

Do not park the motorcycle on a slope or soft ground; the motorcycle may overturn.

PERIODIC MAINTENANCE AND MINOR REPAIR

Periodic inspection, adjustment, and lubrication will keep your motorcycle in the safest and most efficient condition possible. Safety is an obligation of the motorcycle owner. The maintenance and lubrication schedule chart should be considered strictly as a guide to general maintenance and lubrication intervals. YOU MUST TAKE INTO CONSIDERATION THAT WEATHER, TERRAIN, GEOGRAPHICAL LOCATIONS, AND A VARIETY OF INDIVIDUAL USES ALL TEND TO DEMAND THAT EACH OWNER ALTER THIS TIME SCHEDULE TO SHORTER INTERVALS TO MATCH HIS ENVIRONMENT. The most important points of motorcycle inspection, adjustment, and lubrication are explained in the following pages.

WARNING:

If you are not familiar with motorcycle service, this work should be done by a Yamaha dealer.

Tool kit

The service information included in this manual is intended to provide you, the owner, with the necessary information for completing some of your own preventive maintenance and minor repairs. The tools provided in the owner's tool kit are sufficient for most of these purposes; however a torque wrench is also necessary to properly tighten nuts and bolts.



1. Tool kit

U-060

NOTE:

If you do not have a torque wrench available during a service operation requiring one, take your motorcycle to a Yamaha dealer to check the torque settings and adjust them as necessary

U-671

⚠ WARNING:

Modifications to this motorcycle not approved by Yamaha may cause loss of performance, and render it unsafe for use. Consult a Yamaha dealer before attempting any changes.

PERIODIC MAINTENANCE/LUBRICATION

Unit km (miles)

ITEM	REMARKS	BREAK-IN 1,000(600)	EVERY	
			6,000 (4,000) or 6 months	12,000 (8,000) or 12 months
Valve(s)*	Check valve clearance Adjust if necessary	○	○	○
Spark plug(s)	Check condition Clean or replace if necessary	○	○	○
Air filter	Clean Replace if necessary		○	○
Carburetor*	Check idle speed/starter operation Adjust if necessary	○	○	○
Fuel line*	Check fuel hose and vacuum pipe for cracks or damage Replace if necessary		○	○
Fuel filter*	Check condition Replace if necessary			○
Engine oil	Replace (Warm engine before draining).	○	○	○
Engine oil filter*	Replace	○		○
Front brake	Check operation/fluid leakage/See NOTE Correct if necessary		○	○
Rear brake	Check operation Adjust if necessary		○	○
Clutch	Check operation Adjust if necessary		○	○
Rear arm pivot*	Check rear arm assembly for looseness Correct if necessary Moderately repack every 24,000 (16,000) or 24 months ***			○
Wheels*	Check balance/damage/runout/spoke tightens Repair if necessary		○	○
Wheel bearings*	Check balance/damage/runout/spoke tightens Replace if necessary		○	○
Steering bearing*	Check bearings assembly for looseness Correct if necessary Moderately repack every 24,000 (16,000) or 24 months **	○		○

ITEM	REMARKS	BREAK-IN 1,000(600)	EVERY	
			6,000 (4,000) or 6 months	12,000 (8,000) or 12 months
Front forks*	Check operation/oil leakage Repair if necessary		○	○
Rear shock absorber*	Check operation/oil leakage Repair if necessary		○	○
Drive chain	Check chain slack/alignment Adjust if necessary Clean and lube		EVERY 500 (300)	
Fittings/Fasteners*	Check all chassis fittings and fasteners Correct if necessary	○	○	○
Sidestand*	Check operation Replace if necessary	○	○	○
Sidestand switch*	Check operation Clean or replace if necessary	○	○	○
Battery*	Check specific gravity Check breather pipe for proper operation Correct if necessary		○	○

- * It is recommended that these items be serviced by a Yamaha dealer
- ** Medium weight wheel bearing grease (bearing type)
- *** Lithium soap base grease (Bush type)


NOTE:**Brake fluid replacement**

1. When disassembling the master cylinder or caliper cylinder replace the brake fluid. Normally check the brake fluid level and add the fluid as required.
2. On the inner parts of the master cylinder and caliper cylinder replace the oil seals every two years.
3. Replace the brake hose every four years, or if cracked or damaged

Torque specifications

Use a torque wrench to tighten these items. It is recommended that these items be checked occasionally, especially before a long trip.

Always check the tightness of these items whenever they are loosened for any reason.



A (Nut)	B (Bolt)	General torque specifications		
		Nm	m·kg	ft·lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94

Item	Torque		
	Nm	m·kg	ft·lb
Spark plug	13	1.3	9.4
Engine drain plug	34	3.4	25
Oil filter bolt	7	0.7	5.1
Front axle pinch bolt	20	2.0	14
Front axle	58	5.8	42
Rear wheel axle	110	11.0	80
Tension bar bolt	20	2.0	14

Engine oil


1. Oil level measurement
 - a. Place the motorcycle on a level place and hold it in an upright position. Warm up the engine for several minutes.

U 039

NOTE:

Be sure the motorcycle is positioned straight up when checking the oil level, a slight tilt toward the side can produce false readings.

- b. With the engine stopped, check the oil level through the level window located at the lower part of the right side crankcase cover.



- 1 Level window
- 3 Minimum mark

- 2 Maximum mark


U-040

NOTE:

Wait a few minutes until the oil level settles before checking.


- c. The oil level should be between maximum and minimum marks. If the level is low, add sufficient oil to raise it to the proper level.
2. Engine oil and oil filter replacement
 - a. Warm-up the engine for a few minutes.

- b. Stop the engine. Place an oil pan under the engine, and remove the oil filler cap.




1 Oil filler cap

- c. Remove the drain plug and drain the oil.



1 Drain plug

- d. Remove the oil filter bolt and filter element.



1 Oil filter bolt

- e. Reinstall the drain plug (make sure it is tight)

Drain plug torque:
34 Nm (3.4 m·kg, 25 ft·lb)

- f. Install the new oil filter element, new O-ring, and the filter cover, tighten the oil filter bolt.


Oil filter bolt.

7 Nm (0.7 m·kg, 5.1 ft·lb)

U-041

NOTE:

Make sure the O-ring is positioned properly



1. Oil filter element

2. O-ring

g Add oil through the oil filler hole

Periodic oil change:

1.4 L (1.2 Imp qt, 1.5 US qt)

With oil filter replacement.

1.6 L (1.4 Imp qt, 1.7 US qt)

Recommended oil See page 4-4.

U-323

CAUTION:

Do not add any chemical additives. Engine oil also lubricates the clutch and additives could cause clutch slippage.

U-324


CAUTION:

Be sure no foreign material enters the crankcase.


h After replacement of engine oil and/or oil filter, be sure to check for any oil leakage

Air filter


1. Remove the air filter case assembly.




2. Remove the air filter case cover.




3. Remove the air filter element from its case, and clean it with solvent. After cleaning, remove the remaining solvent by squeezing the element.



1 Wing nut



1 Air filter element



2 Element guide

- 4 Apply recommended oil to the entire surface of the filter and squeeze out the excess oil. The element should be wet but not dripping.

Recommended oil SAE10W30 motor oil

5. When installing the air filter element in its case, be sure its sealing surface matches the sealing surface of the case so there is no air leak
6. The air filter element should be cleaned at the specified intervals. It should be cleaned more often if the motorcycle is operated in dusty or wet areas

U-326

CAUTION:

The engine should never be run without the air cleaner element; excessive piston and/or cylinder wear may result.

Carburetor adjustment

The carburetor is a vital part of the engine and requires very sophisticated adjustment. Most adjustments should be left to a Yamaha dealer who has the professional knowledge and experience to do so. However, the following point may be serviced by the owner as part of this routine maintenance.

U-330

CAUTION:


The carburetor was set at the Yamaha factory after many tests. If the settings are disturbed, poor engine performance and damage may result.

H-901

Idle speed adjustment

- 1 Start the engine and warm it up for a few minutes (normally, 1 or 2 minutes) at approximately 1,000 to 2,000 r/min. Occasionally rev the engine to 4,000 to 5,000 r/min. The engine is warm when it quickly responds to the throttle

2. Set the idle to the specified engine speed by adjusting the throttle stop screw, turn the screw in to increase engine speed, turn the screw out to decrease engine speed.



1 Throttle stop screw

Standard idle speed:
1,250 ~ 1,350 r/min


NOTE:

If the specified idle speed cannot be obtained by performing the above adjustment, consult a Yamaha dealer

Throttle cable adjustment**NOTE:**

Before adjusting the throttle cable free play, the engine idling speed should be adjusted.

The throttle cable should have a specified free play in the turning direction at the grip flange. If the play is incorrect, take the following steps for adjustment



- 1 Lock nut 2. Adjuster a. 3 ~ 5 mm (0.12 ~ 0.20 in)

Free play

3 ~ 5 mm (0.12 ~ 0.20 in)

- 1 Loosen the lock nut
- 2 Turn the adjuster in or out until the adjustment is suitable
- 3 Tighten the lock nut

Valve clearance adjustment

The valve clearance becomes larger with use, resulting in improper fuel/air supply and engine noise. To prevent this, the valve clearance must be adjusted regularly. This adjustment, however, should be left to a professional Yamaha service technician.

Spark plug inspection

The spark plug is an important engine component and is easy to inspect. The condition of the spark plug can indicate something of the condition of the engine.

Normally, all spark plugs from the same engine should have the same color on the white porcelain insulator around the center electrode. The ideal color at this point is a medium to light tan color for a motorcycle that is being ridden normally. If one spark plug shows a distinctly different color, there could be something wrong with the engine


Do not attempt to diagnose such problems yourself. Instead, take the motorcycle to a Yamaha dealer.

You should periodically remove and inspect the spark plug because heat and deposits will cause any spark plug to slowly break down and erode. If electrode erosion becomes excessive, or if carbon and other deposits are excessive, you should replace the spark plug with a proper type plug.

Standard spark plug:

C6HSA (NGK) or U20FS-U (ND)

Before installing any spark plug, measure the electrode gap with a wire thickness gauge, adjust the gap to specification as necessary



1 Spark plug gap

Spark plug gap

0.6 ~ 0.7 mm (0.024 ~ 0.028 in)

When installing the plug, always clean the gasket surface and use a new gasket. Wipe off any grime from the threads, and torque the spark plug properly.

Spark plug torque.

13 Nm (1.3 m·kg, 9.4 ft·lb)

U-038

NOTE:


If a torque wrench is not available when you are installing a spark plug, a good estimate of the correct torque is 1/4 to 1/2 turns past finger tight. Have the spark plug torqued to the correct value as soon as possible with a torque wrench.

H-801

Front brake adjustment

The free play at the end of the front brake lever should be 2 ~ 5 mm (0.08 ~ 0.2 in)

1. Loosen the lock nut.
2. Turn the adjuster so that the brake lever movement at the lever end is 2 ~ 5 mm (0.08 ~ 0.2 in) before the adjuster contacts the master cylinder piston.
3. After adjusting, tighten the lock nut.



1 Lock nut 2 Adjuster a 2 ~ 5 mm (0.08 ~ 0.2 in)

U-636

⚠ WARNING:

Check the brake lever free play. Be sure the brake is working properly.

U-641

⚠ WARNING:

A soft or spongy feeling in the brake lever can indicate the presence of air in the brake system. This air must be removed by bleeding the brake system

before the motorcycle is operated. Air in the system will cause greatly diminished braking capability and can result in loss of control and an accident. Have a Yamaha dealer inspect and bleed the system if necessary.

H-871

Rear brake adjustment

U-643

⚠ WARNING:

For brake pedal adjustment, be sure to proceed as follows: (It is advisable to have a Yamaha dealer make this adjustment.)


- 1 Pedal height
 - a. Loosen the adjuster lock nut (for pedal height).
 - b. By turning the adjuster clockwise or counterclockwise, adjust the brake pedal position as shown below
 - c. Secure the adjuster lock nut.

⚠ WARNING:


After adjusting the pedal height, adjust brake pedal free play.

2. Free play

The rear brake should be adjusted to suit the rider's preference, but free play at the brake pedal end must be 20 ~ 30 mm (0.8 ~ 1.2 in). Turn the adjuster on the brake rod clockwise to reduce play, turn the adjuster counterclockwise to increase play.



- 1 Footrest 2 Pedal height 45 ~ 55 mm (1.8 ~ 2.2 in)
 3 Free play 20 ~ 30 mm (0.8 ~ 1.2 in)



- 1 Lock nut 2 Adjuster (for pedal height)



- 1 Adjuster


⚠ WARNING:

1. The rear brake pedal adjustment must be checked anytime chain is adjusted or rear wheel is removed and then reinstalled.
2. Check the operation of the brake light after adjusting the rear brake.

H-833

Brake light switch adjustment

The brake light switch is operated by movement of the brake pedal. To adjust, hold the main body of the switch with your hand so it does not rotate and turn the adjusting nut. Proper adjustment is achieved when the brake light comes on just before the brake begins to take effect.



1 Main body 2 Adjuster

H-814


Checking the front brake pads and rear brake shoes

A wear indicator is attached to each brake to facilitate brake pad and shoe check. This indicator permits a visual check without disassembling the brake.

H-821

FRONT

To check, depress the brake and inspect the wear indicator. If the wear indicator is ALMOST in contact with the disc plate, ask a Yamaha dealer to replace the pads




1 Wear indicator

H-826

REAR

To check, look at the wear indicator while depressing the brake pedal. If the indicator reaches the wear limit line, ask a Yamaha dealer to replace the shoes.



1 Wear indicator

2 Wear limit

H-828

Inspecting the brake fluid level

Insufficient brake fluid may let air enter the brake system, possibly causing the brakes to become ineffective. Before riding, check the brake fluid level and replenish when necessary, observe these precautions.

- 1 When checking the fluid level, make sure the master cylinder top is horizontal by turning the handlebars.

2. Use only the designated quality brake fluid. otherwise, the rubber seals may deteriorate, causing leakage and poor brake performance.


Recommended brake fluids: DOT #4

NOTE:

If DOT#4 is not available, #3 can be used.

3. Refill with the same type of brake fluid; mixing fluids may result in a harmful chemical reaction and lead to poor performance
4. Be careful that water does not enter the master cylinder when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.
5. Brake fluid may erode painted surfaces or plastic parts. Always clean up spilled fluid immediately.

6. Have a Yamaha dealer check the cause if the brake fluid level goes down.



1 Lower level

H-835

Brake fluid replacement

1. Complete fluid replacement should be done only by trained Yamaha service personnel.
2. Have a Yamaha dealer replace the following components when indicated in the schedule or when they are damaged or leaking.

- a. Replace all rubber seals every two years
- b. Replace all hoses every four years.

I-009

Clutch adjustment


This model has two clutch cable length adjusters. The cable length adjuster are used to take up slack from cable stretch and to provide sufficient free play for proper clutch operation.

I-005


Free play adjustment

The clutch should be adjusted to suit the rider's preference, but, free play at the lever pivot should be 3 ~ 5 mm (0.12 ~ 0.20 in). Loosen either the handlebar lever adjuster lock nut or the cable length adjuster lock nut. Turn the cable length adjuster either in or out until proper lever free play is achieved

Clutch lever free play
3 ~ 5 mm (0.12 ~ 0.20 in)



1 Lock nut 2 Adjuster a 3 ~ 5 mm (0.12 ~ 0.20 in)




1 Lock nut 2 Adjuster

Drive chain slack check

NOTE:

Before checking and/or adjusting the chain slack, rotate the rear wheel through several revolutions. Check the chain slack several times to find the point where the chain is the tightest. Check and/or adjust the chain slack where the rear wheel is in this "tight chain" position


To check the chain slack the motorcycle must stand vertically with its both wheels on the ground and without a rider. Check the slack at the position shown in the illustration. The normal vertical deflection is approximately 30 ~ 40 mm (1.2 ~ 1.6 in). If the deflection exceeds 40 mm (1.6 in) adjust the chain slack



a 30 ~ 40 mm (1.2 ~ 1.6 in)


Drive chain slack adjustment

1. Loosen the rear brake adjuster.



1 Adjuster

2. Remove the cotter pin from the rear wheel axle nut.



- | | | |
|------------|-----------------------|------------|
| 1 Axle nut | 2 Cotter pin | 3 Lock nut |
| 4 Adjuster | 5 Marks for alignment | |

3. Loosen the rear wheel axle nut
4. Loosen the lock nuts on each side. To tighten the chain, turn chain adjuster clockwise. To loosen the chain, turn the adjuster counterclockwise and push the wheel forward. Turn each adjuster exactly the same amount to maintain correct axle alignment

(There are marks on each side of swingarm and on each chain adjuster, use them to check for proper alignment.)

U-333

CAUTION:

Too small chain slack will overload the engine and other vital parts; keep the slack within the specified limits.


5. After adjusting, be sure to tighten the lock nuts and the axle nut.

Axle nut torque
110 Nm (11 m·kg, 80 ft·lb)

6. Insert a new cotter pin into the rear wheel axle nut and bend the end of the cotter pin as shown in the illustration (If the nut notch and the cotter pin hole do not match tighten the nut slightly to align them.)

Drive chain lubrication

The chain consists of many parts which work against each other. If the chain is not maintained properly, it will wear out rapidly, therefore, form the habit of periodically servicing the chain. This service is especially necessary when riding in dusty conditions. This motorcycle has a drive chain with small rubber O-rings between the chain plates. Steam cleaning, high-pressure washes, and certain solvent can damage these O-rings. Use only kerosene to clean the drive chain. Wipe it dry, and thoroughly lubricate it with SAE 30 ~ 50W motor oil. Do not use any other lubricants on the drive chain. They may contain solvents that could damage the O-rings.



1 Cotter pin

U-647

⚠ WARNING:

Always use a new cotter pin on the axle nut.

7. Adjust the free play in the brake pedal.

U-645

⚠ WARNING:

Check the operation of the brake light after adjusting the rear brake.

Cable inspection and lubrication

U-646

⚠ WARNING:

Damage to the outer housing of the various cables may cause corrosion and interfere with the movement of the cable. An unsafe condition may result so replace such cables as soon as possible.

Lubricate the inner cable and the cable end. If they do not operate smoothly, ask a Yamaha dealer to replace them.

Recommended lubricant
SAE 10W30 motor oil

I-102

Throttle cable and grip lubrication

The throttle twist grip assembly should be greased at the time that the cable is lubricated, since the grip must be removed to get at the

end of the throttle cable. Two screws clamp the throttle housing to the handlebar. Once these two are removed, the end of the cable can be held high to pour in several drops of lubricant. With the throttle grip disassembled, coat the metal surface of the grip assembly with a suitable all-purpose grease.

I-306

Brake and change pedals

Lubricate the pivoting parts.

Recommended lubricant
Yamaha Chain and Cable Lube or
SAE 10W30 motor oil

I-307

Brake and clutch levers

Lubricate the pivoting parts.

Recommended lubricant:
Yamaha Chain and Cable Lube or
SAE 10W30 motor oil

Sidestand

Lubricate the pivoting parts. Check to see that the sidestand move up and down smoothly.

Recommended lubricant.

Yamaha Chain and Cable Lube or
SAE 10W30 motor oil

U-704

⚠ WARNING:

If the sidestand movement is not smooth, consult a Yamaha dealer.

I-205

Front fork inspection

U-657

⚠ WARNING:

Securely support the motorcycle so there is no danger of it falling over.

1. Visual check

Check any scratch/damage on the inner tube and excessive oil leakage with the front fork.


2. Operation check

Place the motorcycle on a level place.

- a. Hold the motorcycle on an upright position with a rider's hands on the handlebar and apply the front brake.
- b. Pump the front fork up and down for several times.

⚠ CAUTION:

If any damage or unsmooth movement is found with the front fork, consult a Yamaha dealer.



I-509

Rear shock absorber adjustment


Spring preload

If the spring seat is raised, the spring becomes stiffer, and if lowered, it becomes softer

Standard position 2

1. — Softest

5 — Stiffest



1 Softest

2. Stiffest

⚠ WARNING:

Always adjust each shock absorber to the same setting. Uneven adjustment can cause poor handling and loss of stability.


I-603

Steering inspection

Periodically inspect the condition of the steering. Worn out or loose steering bearings may be dangerous.

Place a block under the engine to raise the front wheel off the ground.

Hold the lower end of the front forks and try to move them forward and backward. If any free play can be felt, ask a Yamaha dealer to inspect and adjust the steering. Inspection is easier if the front wheel is removed.



U-657

⚠ WARNING:

Securely support the motorcycle so there is no danger of it falling over.

I-602

Wheel bearings

If the wheel bearings in the front or rear wheel allow play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer inspect the wheel bearings. The wheel bearings should be inspected according to the Maintenance Schedule.

I-700

Battery


Check the level of the battery electrolyte and see that the terminals are tight. Add distilled water if the electrolyte level is low.

⚠ WARNING:

Battery electrolyte is poisonous and dangerous, causing severe burns, etc. It contains sulfuric acid. Avoid contact with skin, eyes or clothing.

Antidote: **EXTERNAL**-Flush with water. **INTERNAL**-Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call a physician immediately.

Eyes: Flush with water for 15 minutes and get prompt medical attention. Batteries produce explosive gases. Keep sparks, flame, cigarettes etc., away. Ventilate when charging or using in an enclosed space. Always shield your eyes when working near batteries. **KEEP OUT OF REACH OF CHILDREN.**


**⚠ CAUTION:**

When inspecting the battery, be sure the breather pipe is routed correctly. If the breather pipe touches the frame or exits in such a way as to cause battery electrolyte or gas to exit onto the frame, structural and cosmetic damage to the motorcycle can occur.

Replenishing the battery fluid

A poorly maintained battery will deteriorate quickly. The battery fluid should be checked at least once a month.

- 1 The level should be between the upper and lower level marks. Use only distilled water if refilling is necessary.



1 Upper level

2 Lower level

CAUTION:

Normal tap water contains minerals which are harmful to a battery; therefore, refill only with distilled water.

WARNING:

Battery fluid on the chain can cause premature failure and possibly an accident.

2. When the motorcycle will not be used for a month or longer, remove the battery and store it in a cool, dark place. Completely recharge the battery before reusing.
3. If the battery will be stored for a longer period than the above, check the specific gravity of the fluid at least once a month and recharge the battery when it is too low.


4. Always make sure the connections are correct when putting the battery back in the motorcycle

Make sure the breather pipe is properly connected and is not damaged or obstructed

I-918

Fuse replacement

1. The fuse is located under the seat.



1 Fuse

2. If a fuse is blown, turn off the ignition switch and the switch in the circuit in question. Install a new fuse of proper amperage. Turn on the switches, and see if the electrical device operates. If the fuse immediately blows again, consult a Yamaha dealer.

U-344

CAUTION:


Do not use fuses of higher amperage rating than those recommended. Substitution of a fuse of improper rating can cause extensive electrical system damage and possibly a fire.

I-831


Replacing the headlight bulb

If the headlight bulb burns out, replace the bulb as follows

1. Remove the 2 screws holding the light unit assembly



2. Disconnect the lead and remove the cover



1 Cover

3. Turn the bulb holder counterclockwise and remove the defective bulb.



1 Bulb holder

U-660

⚠ WARNING:

Keep flammable products or your hands away from the bulb while it is on, it will be hot. Do not touch the bulb until it cools down.

4. Slip a new bulb into position and secure it in place with the bulb holder.

5. Reinstall the cover, leads and light unit assembly. Adjust the headlight beam if necessary

I-802


Headlight beam adjustment

U-343

CAUTION:

For the headlight beam adjustment, be sure to proceed as follows; (It is advisable to have a Yamaha dealer make this adjustment.)

- 1 Horizontal adjustment.
To adjust the beam to the right, turn the adjusting screw clockwise
To adjust the beam to the left, turn the screw counterclockwise
- 2 Vertical adjustment:
To raise the beam, turn the adjusting screw clockwise
To lower the beam, turn the screw counterclockwise.




1 Horizontal adjusting screw 2 Vertical adjusting screw

J-244


Front wheel removal

- 1 Elevate the front wheel by placing a suitable stand under the engine
2. Remove the speedometer cable at the speedometer gear housing



1 Speedometer cable

- 3 Loosen the pinch bolt securing the wheel axle.



1 Pinch bolt

2. Front axle

4. Remove the axle and the front wheel. Make sure the motorcycle is properly supported.

U-054

NOTE: _____

Do not depress the brake lever when the disc is off the caliper as the brake pads will be forced shut.


J-217

Front wheel installation


When installing the front wheel, reverse the removal procedure

Pay attention to the following points:

1. Make sure the wheel hub and the speedometer clutch assembly are installed with the projections meshed into the slots.



- 2 Make sure the projecting portion (torque stopper) of the speedometer housing is positioned correctly.



3. Make sure the axle is properly torqued.

Tightening torque:
58 Nm (5.8 m·kg, 42 ft·lb)

4. Before tightening the pinch bolt, compress the front forks several times to check for proper fork operation.
- 5 Tighten the axle pinch bolt.

Axle pinch bolt torque:
20 Nm (2 m·kg, 14 ft·lb)

J-312

Rear wheel removal


U-662

⚠ WARNING:

It is advisable to have a Yamaha dealer service the rear wheel.


1. Elevate the rear wheel by placing a suitable stand under the engine

- Remove the tension bar and the brake rod from the brake shoe plate. The tension bar can be removed by removing the cotter pin and nut from the tension bar bolt. The brake rod can be removed by removing the adjuster.



1 Tension bar 2 Brake rod 3 Adjuster

- Loosen the lock nuts of the right and left chain adjusters and loosen the adjusters
- Remove the axle nut cotter pin and the axle nut



1 Axle nut 2 Cotter pin 3 Lock nut
4 Adjuster 5 Marks for alignment

- The rear wheel assembly, the collar, the chain adjusters, etc., can be removed from the motorcycle by pulling the wheel axle.

U-056

NOTE: _____

You do not have to disassemble the chain in order to remove or install the rear wheel

Rear wheel installation

When installing the rear wheel, reverse the removal procedure. Pay attention to the following points

1. Adjust the drive chain
2. Make sure the axle nut and tension bar bolt are properly torqued, and a new cotter pin is installed.

U-647

⚠ WARNING:

Always use a new cotter pin on the axle nut.

U-716

⚠ WARNING:

Always use a new cotter pin on the tension bar bolt.

Tightening torque.

Axle nut

110 Nm (11 m·kg, 80 ft·lb)

Tension bar bolt

20 Nm (2.0 m·kg, 14 ft·lb)

- 3 Adjust the rear brake (See page 6-15.)

U-645

⚠ WARNING:

Check the operation of the brake light after adjusting the rear brake.

Troubleshooting

Although Yamaha motorcycles receive a rigid inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems can cause poor starting and a loss of power. The troubleshooting chart describes a quick, easy procedure for checking these systems.


If your motorcycle requires any repair, bring it to a Yamaha dealer. The skilled technicians at a Yamaha dealer have the tools, experience, and know-how to properly service your motorcycle. Use only genuine Yamaha parts on your motorcycle. Imitation parts may look like Yamaha parts, but they are often inferior. Consequently, they have a shorter service life and can lead to expensive repair bills.

Troubleshooting chart

EUU66300

1 WARNING:

Never check the fuel system while smoking or in the vicinity of an open flame



CLEANING AND STORAGE

A. CLEANING

Frequent thorough cleaning of your motorcycle will not only enhance its appearance but will improve its general performance and extend the useful life of many components

- 1 Before cleaning the motorcycle.
 - a. Block off the end of exhaust pipe to prevent water entry; a plastic bag and strong rubber band may be used.
 - b. Make sure the spark plug(s) and all filler caps are properly installed.
- 2 If the engine case is excessively greasy, apply degreaser with a paint brush. Do not apply degreaser to the chain, sprockets, or wheel axles
- 3 Rinse the dirt and degreaser off with a garden hose, use only enough pressure to do the job

CAUTION

Excessive hose pressure may cause water seepage and contamination of wheel bearings, front forks, brakes and transmission seals. Many expensive repair bills have resulted from improper high pressure detergent applications such as those available in coin-operated car washers.

- 4 Once the majority of the dirt has been hosed off, wash all surfaces with warm water and mild, detergent-type soap. An old tooth brush or bottle brush is handy for hard-to-get-to places.
5. Rinse the motorcycle off immediately with clean water and dry all surfaces with a chamois, clean towel, or soft absorbent cloth.
- 6 Dry the chain and lubricate it to prevent rust

- 7 Clean the seat with a vinyl upholstery cleaner to keep the cover pliable and glossy.
8. Automotive-type wax may be applied to all painted and chrome-plated surfaces. Avoid combination cleaner-waxes. Many contain abrasives which may mar the paint or protective finish. When finished, start the engine and let it idle for several minutes.

K-012

B. STORAGE

Long term storage (60 days or more) of your motorcycle will require some preventive procedures to guard against deterioration. After thoroughly cleaning the motorcycle, prepare for storage as follows.

1. Drain the fuel tank, fuel lines, and carburetor float bowl(s)
2. Remove empty fuel tank, pour a cup of SAE 10W30 or 20W40 motor oil in tank,

shake the tank to coat the inner surfaces thoroughly and drain off the excess oil. Reinstall the tank.

3. Remove the spark plug, pour about one tablespoon of SAE 10W30 or 20W40 motor oil in the spark plug hole and reinstall the spark plug. Turn the engine over several times (ground spark plug lead wires) to coat the cylinder walls with oil.

U-664

WARNING:

When using the starter motor to crank the engine, remove the spark plug wires, and ground them to prevent sparking.

4. Remove the drive chain. Thoroughly clean the chain with kerosene and lubricate. Reinstall the chain or store it in a plastic bag (tied to frame for safe-keeping).

5. Lubricate all control cables.
6. Block up the frame to raise both wheels off the ground.
7. Tie a plastic bag over the exhaust pipe outlet to prevent moisture from entering.
8. If storing in a humid or salt-air atmosphere, coat all exposed metal surfaces with a light film of oil. Do not apply oil to any rubber parts or the seat cover.
9. Remove the battery and charge it. Store it in a dry place and recharge it once a month. Do not store the battery in an excessively warm or cold place (less than 0 °C(30 °F) or more than 30 °C(90 °F))


U-058

NOTE: _____

Make any necessary repairs before storing the motorcycle.

SPECIFICATIONS

Model	XV250W
Dimension Overall length Overall width Overall height Seat height Wheel base Minimum ground clearance	2,190 mm (86 2 in) 725 mm (28 5 in) 1,045 mm (41 1 in) 685 mm (27 0 in) 1,490 mm (58 7 in) 145 mm (5 7 in)
Basic weight With oil and full fuel tank	147 kg (324 lb)
Minimum turning radius	2,800 mm (110 2 in)
Engine Type Model Cylinder arrangement Displacement Bore x Stroke Compression ratio Starting system Lubrication system	Air cooled 4-stroke, gasoline, SOHC 3LV1 V-2 cylinder 248 cm ³ 49 x 66 mm (1 93 x 2 60 in) 10 1 Electric starter Wet sump

Model	XV250W
<p>Engine oil (4-cycle): Type</p>  <p>Capacity Periodic oil change With oil filter replacement Total amount</p>	<p>SAE 20W40 type SE motor oil (if temperature does not go below 5°C/40°F)</p> <p>SAE 10W30 type SE motor oil (if temperature does not go above 15°C/60°F)</p> <p>1.4 L (1.2 Imp qt, 1.5 US qt) 1.6 L (1.4 Imp qt, 1.7 US qt) 1.8 L (1.6 Imp qt, 1.9 US qt)</p>
Air filter.	Wet type element
<p>Fuel Type</p> <p>Tank capacity Reserve amount</p>	<p>Regular gasoline For Australia Unleaded fuel only</p> <p>9.5 L (2.1 Imp gal, 2.5 US gal) 2.6 L (0.6 Imp gal, 0.9 US gal)</p>
<p>Carburetor. Type/Manufacturer</p>	BDS26/MIKUNI
<p>Spark plug. Type/Manufacturer Gap</p>	<p>C6HSA (NGK) or U20FS-U (ND) 0.6 ~ 0.7 mm (0.024 ~ 0.028 in)</p>

Model	XV250W
Clutch type	Wet, multi-disc
Transmission Primary reduction system Primary reduction ratio Secondary reduction system Secondary reduction ratio Transmission type Operation Gear ratio 1st 2nd 3rd 4th 5th	Spur Gear 72/23 (3 130) Chain drive 45/16 (2 813) Constant mesh 5-speed Left foot operation 37/14 (2.643) 32/19 (1 684) 29/23 (1 261) 26/26 (1 000) 23/28 (0 821)
Chassis Frame type Caster angle Trail	Double cradle 32° 120 mm (4 7 in)
Tire. Type Size — Front Rear	With tube 3 00-18-4PR 130/90-15 M/C 66P
Brake Front brake type Operation Rear brake type Operation	Single, Disk brake Right hand operation Drum brake Right foot operation

Model	XV250W
Suspension Front Rear	Telescopic fork Swing arm
Shock absorber. Front Rear	Coil spring, Oil damper Coil spring, Oil damper
Wheel Travel Front Rear	140 mm (5.5 in) 100 mm (3.9 in)
Electrical Ignition system Generator system Battery type/capacity	TCI (Digital) AC magneto generator GM10-3A-2/12V10AH
Headlight type	Quartz bulb
Bulb wattage/Quantity. Headlight Tail/brake light Flasher light Meter light Auxiliary light	12V 60W/55W 12V 5W/21W 12V 21W x 4 12V 3W 12V 3 4W
Indicator light wattage/quantity "NEUTRAL" "HIGH BEAM" "TURN"	12V 3W 12V 1 7W 12V 3W

NOISE REGULATION (For Australia)

"TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED"

Owners are warned that the law may prohibit.

- (a) The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; and
- (b) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.



YAMAHA MOTOR CO.,LTD.

IWATA, JAPAN

PRINTED IN JAPAN

89·01 - 0.64 x 1 CR

(英)

