



**OWNER'S MANUAL**

**YAMAHA**

***XV750G***

**4PV-28199-20**

EAA00100

**XV750G**

**OWNER'S MANUAL**

**©1994 by Yamaha Motor Co., Ltd.**

**1st Edition, June 1994**

**All rights reserved. Any reprinting or  
unauthorized use without the written  
permission of Yamaha Motor Co., Ltd.  
is expressly prohibited.**

**Printed in Japan**

## INTRODUCTION

Congratulations on your purchase of the Yamaha XV750G. This model is the result of Yamaha's vast experience in the production of fine sporting, touring, and pace-setting racing machines. It represents the high degree of craftsmanship and reliability that have made Yamaha a leader in these fields.

This manual will give you an understanding of the operation, inspection, and basic maintenance of this motorcycle. If you have any questions about the operation or maintenance of your motorcycle, please consult a Yamaha dealer.

Particularly important information is distinguished in this manual by the following notations



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

 **WARNING**

Failure to follow WARNING instructions could result in severe injury or death to the motorcycle operator, a bystander or a person inspecting or repairing the motorcycle.

**CAUTION:**

A CAUTION indicates special precautions that must be taken to avoid damage to the motorcycle.

**NOTE:**

A NOTE provides key information to make procedures easier or clearer.

EUU00000

**NOTE:**

This manual should be considered a permanent part of this motorcycle and should remain with it even if the motorcycle is subsequently sold.

EUU13800

**NOTE:**

Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your machine and this manual. If there is any question concerning this manual, please consult your Yamaha dealer.



## **WARNING**

---

**PLEASE READ THIS MANUAL CAREFULLY  
AND COMPLETELY BEFORE OPERATING  
THIS MOTORCYCLE.**

---

# CONTENTS

SAFETY INFORMATION . . . . .	1-1	Speedometer . . . . .	5-6
LOCATION OF THE IMPORTANT LABELS .. . . .	2-1	Tachometer . . . . .	5-6
DESCRIPTION .. . . .	3-1	Handlebar switches . . . . .	5-7
MOTORCYCLE IDENTIFICATION . . . . .	4-1	Clutch lever . . . . .	5-8
Identification numbers record . . . . .	4-1	Shift pedal . . . . .	5-8
Vehicle identification number . . . . .	4-2	Front brake lever . . . . .	5-9
Engine serial number . . . . .	4-2	Rear brake pedal . . . . .	5-9
CONTROL FUNCTIONS . . . . .	5-1	Fuel tank cap . . . . .	5-9
Main switch . . . . .	5-1	Fuel cock . . . . .	5-10
Indicator lights . . . . .	5-2	Starter lever (CHOKE) . . . . .	5-11
Oil level indicator circuit check . . . . .	5-3	Steering lock . . . . .	5-12
Fuel level indicator circuit check . . . . .	5-5	Seat . . . . .	5-13
		Helmet holder . . . . .	5-14
		Storage box . . . . .	5-14
		Rear shock absorber . . . . .	5-15
		Sidestand . . . . .	5-15
		Sidestand/clutch switch operation check . . . . .	5-16

PRE-OPERATION CHECKS .....	6-1
Brakes .....	6-3
Brake fluid leakage (Front).....	6-3
Clutch .....	6-4
Throttle grip.....	6-4
Engine oil.....	6-4
Final gear oil.....	6-5
Tires .....	6-5
Tubeless tires and cast wheels .....	6-7
Fittings/Fasteners.....	6-9
Lights and signals .....	6-9
Switches .....	6-9
Battery.....	6-9
Fuel.....	6-9

## OPERATION AND IMPORTANT

RIDING POINTS.....	7-1
Starting and warming up	
a cold engine .....	7-1
Starting a warm engine .....	7-4
Shifting .....	7-4

Engine break-in.....	7-5
Parking.....	7-6

## PERIODIC MAINTENANCE AND

MINOR REPAIR .....	8-1
Tool kit.....	8-1
Periodic maintenance / lubrication.....	8-3
Torque specifications.....	8-5
Engine oil .....	8-6
Final gear oil .....	8-9
Air filter.....	8-11
Carburetor adjustment .....	8-13
Idle speed adjustment .....	8-13
Throttle cable adjustment .....	8-14
Valve clearance adjustment.....	8-14
Spark plug inspection .....	8-15
Front brake adjustment .....	8-16
Rear brake adjustment.....	8-17
Brake light switch adjustment .....	8-19
Checking the front brake pads and	
rear brake shoes.....	8-19
Inspecting the brake fluid level.....	8-20

Brake fluid replacement .....	8-21
Clutch adjustment.....	8-22
Cable inspection and lubrication .....	8-22
Throttle cable and grip lubrication ..	8-23
Brake and shift pedals .....	8-23
Brake and clutch levers .....	8-23
Center and sidestand.....	8-23
Rear suspension .....	8-24
Front fork inspection .....	8-24
Rear shock absorber adjustment .....	8-25
Steering inspection.....	8-25
Wheel bearings .....	8-26
Battery .....	8-26
Replenishing the battery fluid .....	8-27
Fuse replacement .....	8-28
Headlight bulb replacement .....	8-30
Front wheel removal .....	8-32
Front wheel installation. ....	8-33
Rear wheel removal.....	8-35
Rear wheel installation.....	8-37
Troubleshooting .....	8-38
Troubleshooting chart.....	8-39

CLEANING AND STORAGE .....	9-1
A. Cleaning... ..	9-1
B. Storage.....	9-2

SPECIFICATIONS .....	10-1
----------------------	------

HOW TO USE THE CONVERSION TABLE .....	11-1
--	------

NOISE REGULATION (FOR Australia).....	12-1
--	------

WIRING DIAGRAM	
----------------	--

## **⚠ SAFETY INFORMATION**

**TWO-WHEELED MOTORCYCLES ARE SINGLE TRACK VEHICLES. THEIR SAFE USE AND OPERATION ARE DEPENDENT UPON THE USE OF PROPER RIDING TECHNIQUES AS WELL AS THE EXPERTISE OF THE OPERATOR. EVERY OPERATOR SHOULD KNOW THE FOLLOWING REQUIREMENTS BEFORE RIDING.**

**HE OR SHE SHOULD:**

- 1. OBTAIN THOROUGH INSTRUCTIONS FROM A COMPETENT SOURCE ON ALL ASPECTS OF MOTORCYCLE OPERATION.**
- 2. OBSERVE THE WARNINGS AND MAINTENANCE REQUIREMENTS IN THE OWNER'S MANUAL.**
- 3. OBTAIN QUALIFIED TRAINING IN SAFE AND PROPER RIDING TECHNIQUES.**
- 4. OBTAIN PROFESSIONAL TECHNICAL SERVICE AS INDICATED BY THE OWNER'S MANUAL AND/OR WHEN MADE NECESSARY BY MECHANICAL CONDITIONS.**

### **SAFE RIDING**

- 1. Always make pre-operation checks. Careful checks may help prevent an accident.**
- 2. This motorcycle is designed to carry the operator and a passenger.**

- 3. The failure of motorists to detect and recognize motorcycles in traffic is the predominating cause of automobile/motorcycle accidents. Many accidents have been caused by an automobile driver who did not see the motorcycle. Making yourself conspicuous appears to be very effective in reducing the chance of this type of accident.**

**Therefore:**

- a. Wear a brightly colored jacket.**
  - b. Use extra caution when you approach and pass through intersections, since intersections are the most likely places for motorcycle accidents.**
  - c. Ride where other motorists can see you. Avoid riding in another motorist's "blind spot".**
- 4. Many accidents involve inexperienced operators. In fact, many operators who have been involved in accidents do not even have a current motorcycle license.**
- a. Make sure you are qualified. Also, only lend your motorcycle to experienced operators.**
  - b. Know your skills and limits. Staying within your limits may help you to avoid an accident.**
  - c. We recommend that you practice riding your motorcycle where there is no traffic until you have become thoroughly familiar with your motorcycle and all of its controls.**

5. Many motorcycle accidents have been caused by motorcycle operator errors. A typical error made by the operator is veering wide on a turn due to **EXCESSIVE SPEED** or undercornering (insufficient lean angle for the speed).
  - a. Always obey the speed limits and never travel faster than warranted by road and traffic conditions.
  - b. Always signal before turning or changing lanes. Make sure other motorists see you.
6. The operator's and passenger's posture are important for proper control.
  - a. The operator should keep both hands on the handlebars and both feet on the operator footrests during operation to maintain control of the motorcycle.
  - b. The passenger should always hold on to the operator, or the seat strap or grab bar if the motorcycle is so equipped, with both hands and keep both feet on the passenger footrests.
  - c. Never carry a passenger unless he or she can firmly place both feet on the passenger footrests.
7. Never ride under the influence of alcohol or drugs.
8. This motorcycle is designed for on-road use only. It is not suitable for off-road use.

## **PROTECTIVE APPAREL**

The majority of fatalities from motorcycle accidents are the result of head injuries. The use of a safety helmet is the single most critical factor in the prevention or reduction of head injuries.

1. Always wear an approved helmet.
2. Wear a face shield or goggles. Wind on your unprotected eyes could contribute to an impairment of vision which could delay seeing a hazard.
3. The use of heavy boots, jacket, trousers, gloves, etc. is effective in preventing or reducing abrasions or lacerations.
4. Never wear loose fitting clothing. It could catch on the control levers, footrests, or wheels and cause injury or accident.
5. Never touch the engine or exhaust system during or after operation. They become very hot and can cause burns. Always wear protective clothing that covers your legs, ankles, and feet.
6. A passenger should also observe the above precautions.

## **MODIFICATION**

Modifications made to the motorcycle not approved by Yamaha, or the removal of original equipment, may render your motorcycle unsafe for use and may cause severe personal injury. Modifications may also make your motorcycle illegal to use.

## **LOADING AND ACCESSORIES**

Adding accessories or cargo to your motorcycle can adversely affect stability and handling if the weight distribution of the machine is changed. To avoid the possibility of an accident, extreme caution should be used if adding cargo or accessories to your motorcycle. Use extra care if riding a motorcycle which has added cargo or accessories. Here are some general guidelines to follow if loading cargo or adding accessories to your motorcycle:

### **LOADING**

The total weight of the operator, passenger, accessories and cargo must not exceed the maximum load limit of 235 kg.

When loading within these weight limits, keep the following in mind:

1. Cargo and accessory weight should be kept as low and close to the motorcycle as possible. Be sure to distribute the weight as evenly as possible on both sides of the machine to minimize imbalance or instability.
2. Shifting weights can create a sudden imbalance. Make sure that accessories and cargo are securely attached to the motorcycle before riding. Recheck accessory mounts and cargo restraints frequently.

3. **Never attach any large or heavy items to the handlebars, front forks, or front fender. These items, including such cargo as sleeping bags, duffle bags, or tents, can create unstable handling or slow steering response.**

## **ACCESSORIES**

**Genuine Yamaha accessories have been specifically designed for use on this motorcycle. Since Yamaha cannot test all other accessories which may be available, you must personally be responsible for the proper selection, installation and use of non-Yamaha accessories. You should use extreme caution when selecting and installing any accessories.**

**Keep in mind these guidelines for mounting accessories in addition to those provided under "LOADING".**

1. **Never install accessories or carry cargo that would impair the performance of your motorcycle. Carefully inspect the accessory before using it to make sure it does not in any way reduce ground clearance or cornering clearance, limit suspension travel, steering travel or control operation, or obscure lights or reflectors.**
  - a. **Accessories fitted to the handlebar or the front fork area can create instability due to improper weight distribution or aerodynamic changes. If accessories are added to the handlebar or front fork area, they must be as lightweight as possible and should be kept to a minimum.**

- b. Bulky or large accessories may seriously affect the stability of the motorcycle due to aerodynamic effects. Wind may attempt to lift the motorcycle, or the motorcycle may become unstable in cross winds. These accessories may also cause instability when being passed by or passing large vehicle.
  - c. Certain accessories can displace the operator from his or her normal riding position. This improper position limits the freedom of movement of the operator and may limit control ability. Therefore such accessories are not recommended.
2. Caution must be used if adding electrical accessories. If these accessories exceed the capacity of the motorcycle's electrical system, an electric failure could result, which could cause a dangerous loss of lights or engine power.

## **GASOLINE AND EXHAUST GAS**

1. **GASOLINE IS HIGHLY FLAMMABLE:**
- a. Always turn off the engine when refueling.
  - b. Take care not to spill any gasoline on the engine or exhaust pipe(s)/muffler(s) when refueling.
  - c. Never refuel while smoking or in the vicinity of an open flame.
2. Never start the engine or let it run for any length of time in a closed area. The exhaust fumes are poisonous and may cause loss of consciousness and death within a short time. Always operate your motorcycle in an area that has adequate ventilation.




3. Always turn off the engine before leaving the motorcycle unattended and remove the ignition key. When parking the motorcycle, note the following:
  - a. The engine and exhaust pipe(s)/muffler(s) may be hot. Park the motorcycle in a place where pedestrians or children are not likely to touch these hot areas.
  - b. Do not park the motorcycle on a slope or soft ground; the motorcycle may fall over.
  - c. Do not park the motorcycle near a flammable source, e.g. a kerosene heater, or near an open flame. The motorcycle could catch fire.
4. When transporting the motorcycle in another vehicle, be sure it is kept upright and that the fuel cock(s) is turned to "ON" or "RES" (for vacuum type)/"OFF" (for manual type). If it should lean over, gasoline may leak out of the carburetor or fuel tank.
5. If you should swallow any gasoline, inhale a lot of gasoline vapor, or allow gasoline to get in your eye(s), see your doctor immediately. If any gasoline spills on your skin or clothing, immediately wash it off with soap and water and change your clothes.

## LOCATION OF THE IMPORTANT LABEL

Please read the following label carefully before operating this motorcycle.



# DESCRIPTION



- |                       |                           |
|-----------------------|---------------------------|
| 1 Rear flasher light  | 12 Tail/brake light       |
| 2 Rear shock absorber | 13 Shift pedal            |
| 3 Fuel tank           | 14 Front wheel            |
| 4 Front flasher light | 15 Clutch lever           |
| 5 Front fender        | 16 Speedometer            |
| 6 Brake pedal         | 17 Main switch            |
| 7 Footrest            | 18 Tachometer             |
| 8 Muffler             | 19 Brake lever            |
| 9 Rear wheel          | 20 Throttle grip          |
| 10 Headlight          | 21 Right handlebar switch |
| 11 Seat               | 22 Left handlebar switch  |

## MOTORCYCLE IDENTIFICATION

EAA60401

### Identification numbers record


1. KEY IDENTIFICATION NUMBER:

2. VEHICLE IDENTIFICATION NUMBER:

3. ENGINE SERIAL NUMBER:

Your key identification number is stamped on your key as shown in the following illustration.


Record this number in the space provided for reference if you need a new key.



Record your vehicle identification number and engine serial number in the spaces provided to assist you in ordering spare parts from your Yamaha dealer or for reference in case your vehicle is stolen.

## Vehicle identification number

The vehicle identification number is stamped into the steering head pipe.



1 Vehicle identification number


EUU00400

### NOTE:

The vehicle identification number is used to identify your motorcycle and may be used to register your motorcycle with the licensing authority in your state.

## Engine serial number

The engine serial number is stamped into the crankcase.



1 Engine serial number

EUU00300


### NOTE:

The first three digits of these numbers are for model identification, the remaining digits are the unit production number. Keep a record of these numbers for reference when ordering parts from a Yamaha dealer.

## CONTROL FUNCTIONS

### Main switch

The main switch controls the ignition and lighting systems. Its operation is described below.



#### ON:

Electrical circuits are switched on, and the headlight, meter light, and taillight come on. The engine can be started. The key cannot be removed in this position.

#### OFF:

All electrical circuits are switched off. The key can be removed in this position.

#### LOCK:

The steering is locked in this position, and all electrical circuits are switched off. The key can be removed in this position. Refer to "Steering lock" (page 5-12) for operation instructions.


#### PARKING:

The steering is locked in this position, and the taillight comes on but all other circuits are off. The key can be removed in this position.

#### NOTE:

Always turn the main switch to "OFF" or "LOCK" and remove the key when the motorcycle is unattended.

## Indicator lights



- 1 "TURN" indicator light
- 2 "NEUTRAL" indicator light
- 3 "HIGH BEAM" indicator light
- 4 "OIL LEVEL" indicator light
- 5 "FUEL LEVEL" indicator light

"TURN" indicator light (orange):  
This indicator flashes when the turn switch is "ON".

"NEUTRAL" indicator light (green):  
This indicator comes on when the transmission is in neutral.


"HIGH BEAM" indicator light (blue):  
This indicator comes on when the headlight high beam is used.

"OIL LEVEL" indicator light (red):  
This indicator comes on when the oil level is low. This light circuit can be checked by the following procedure.

### **CAUTION**

**Do not run the motorcycle until you know it has sufficient engine oil.**


### Oil level indicator circuit check



"FUEL LEVEL" indicator light (red):


When the fuel level drops below approximately 2.5 L, this light will come on. When this light comes on, switch the fuel cock to "RES." Then, fill the tank at the first opportunity

## Fuel level indicator circuit check



## Speedometer


The speedometer shows riding speed. This speedometer is equipped with an odometer and trip odometer. The trip odometer can be reset to "0" with the reset knob. Use the odometer to estimate how far you can ride on a tank of fuel before going to "RESERVE". This information will enable you to plan fuel stops in the future.



- 1 Speedometer
- 2 Odometer
- 3 Trip odometer
- 4 Reset knob

## Tachometer

This model is equipped with an electric tachometer so the rider can monitor the engine speed and keep it within the ideal power range.




- 1 Tachometer
- 2 Red zone

EUU30400

## CAUTION:

**Do not operate in the red zone**  
**Red zone: 7,000 r/min and above.**

## Handlebar switches



- |                            |                        |
|----------------------------|------------------------|
| 1 "PASS" switch            | 1 "ENGINE STOP" switch |
| 2 "LIGHTS" (Dimmer) switch | 2 "START" switch       |
| 3 "TURN" signal switch     |                        |
| 4 "HORN" switch            |                        |

### "PASS" switch

Press the switch to operate the passing light.

### "LIGHTS" (Dimmer) switch

Turn the switch to "HI" for the high beam and to "LO" for the low beam.

### "TURN" signal switch

This model is equipped with self-cancelling turn signals. To signal a right-hand turn, push the switch to the right; to signal a left-hand turn, push the switch to the left. Once the switch is released it will return to the center position. To cancel the signal, push the switch in after it has returned to the center position. If the switch is not cancelled by hand, it will self-cancel after the motorcycle has travelled for about 10 seconds or approximately 150 meters whichever is greater. The self-cancelling mechanism only operates when the motorcycle is moving; thus the signal will not self-cancel while you are stopped at an intersection.

### "HORN" switch

Press the switch to sound the horn.

EAB60901

### **"ENGINE STOP" switch**

The engine stop switch is a safety device for use in an emergency such as when the motorcycle overturns or if trouble occurs in the throttle system. Turn the switch to "RUN" to start the engine. In case of emergency, turn the switch to "OFF" to stop the engine.

EAB60701

### **"START" switch**

The starter motor cranks the engine when pushing the starter switch.

EUU30700

### **CAUTION:**

**See starting instructions prior to starting the engine.**

EAB70001

### **Clutch lever**

The clutch lever is located on the left handlebar, and the starting circuit cutoff switch is incorporated in the clutch lever holder. Pull the clutch lever to the handlebar to disengage the clutch, and release the lever to engage the clutch. The lever should be pulled rapidly and released slowly for smooth clutch operation. (Refer to the engine starting procedures for a description of the starting circuit cutoff switch.)

EAB80001

### **Shift pedal**


This motorcycle is equipped with a constant-mesh 5-speed transmission. The shift pedal is located on the left side of the engine and is used in combination with the clutch when shifting.

EAC00101

## Fuel tank cap

### TO OPEN:


Insert the key and turn it 1/4 turn clockwise. The lock will be released and the cap can be opened.



1. Open

### TO CLOSE:

Push the tank cap into position with the key inserted. To remove the key, turn it counterclockwise to the original position.



1 Shift pedal

N Neutral

EAB90001

## Front brake lever

The front brake lever is located on the right handlebar. Pull it toward the handlebar to apply the front brake.

EAB90101

## Rear brake pedal

The rear brake pedal is on the right side of the motorcycle. Press down on the brake pedal to apply the rear brake.

**NOTE:**

This tank cap cannot be closed unless the key is in the lock. The key cannot be removed if the cap is not locked properly.


**⚠ WARNING**

Be sure the cap is properly installed and locked in place before riding the motorcycle.

**Fuel cock**

The negative pressure fuel cock supplies fuel from the tank to the carburetor(s) while filtering it also.

The fuel cock has the following three positions:



**ON:** With the lever in this position, fuel flows if the engine is running but stops if the engine is not running.

**RES:** This indicates reserve. If you run out of fuel while riding, move the lever to "PRI", start the engine, then switch to "RES". FILL THE TANK AT THE FIRST OPPORTUNITY. BE SURE TO SET THE LEVER TO "ON" AFTER REFUELLING.

**NOTE:**

The fuel cock operates on vacuum from the engine when set at "ON" or "RES". If the line connecting the cock to the carburetor intake manifold is not connected or has a leak, the cock will not function properly.


**PRI:** This indicates prime. With the lever in this position, fuel flows whether the engine is running or not. If the fuel tank is completely empty, refill the tank, prime the carburetor in this position, and then switch to "ON" after starting the engine.

**Starter lever (CHOKE)**

The starter lever is located on the left handlebar. Starting a cold engine requires a richer fuel mixture. In such a case, turn the starter lever to the left. After the engine is warm, turn the lever to its original position.

**NOTE:**



Refer to "Starting and warming up a cold engine" for proper operation.



1 Starter lever (CHOKE)

## Steering lock

The steering is locked when the main switch is turned to "LOCK." To lock the steering, turn the handlebars all the way to the left or right. With the key at "OFF," push it into the main switch and release it, turn it counterclockwise to "LOCK," and remove it. To release the lock, turn the key to "OFF".



1 Push

2 Release

3 Turn

EUU61400




## WARNING


**Never turn the key to "LOCK" when the motorcycle is moving.**

## Seat

1. Remove the side covers.
2. Remove the seat by removing the bolts.



3. When reinstalling the seat, insert the lobe(s) on the rear of the seat into the receptacle(s) on the frame, then tighten the bolts.



4. Reinstall the side covers.

EUU01700

### **NOTE:**

Make sure that the seat is securely fitted.


## Helmet holder

To open the helmet holder, insert the key in the lock and turn it as shown. To lock the helmet holder, replace the holder in its original position.

EUU72900


## WARNING

Never ride with a helmet in the helmet holder. The helmet may hit objects, causing loss of control and possibly an accident.



## Storage box


The storage box is located inside the left side cover.



1 Left side cover

## Rear shock absorber

The spring preload of the rear shock absorber can be adjusted to suit the rider's preference, motorcycle's load (ex: optional accessories etc.) and road conditions. Refer to page 8-25 for proper adjustment procedures.



1. Spring preload adjuster

## Sidestand

This model is equipped with an ignition circuit cut-off system. The motorcycle must not be ridden when the sidestand is down. The sidestand is located on the left side of the frame. (Refer to page 7-1 for an explanation of this system.)

### **WARNING**

**This motorcycle must not be operated with the sidestand in the down position. If the stand is not properly retracted, it could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha has designed into this motorcycle a lockout system to assist the operator in fulfilling the responsibility of retracting the sidestand. Please check carefully the operating instructions listed below and if there is any indication of a malfunction, return the motorcycle to a Yamaha dealer immediately for repair.**

**Sidestand/clutch switch operation check**

Check the operation of the sidestand switch and clutch switch against the information below.

EUU69000

**⚠ WARNING**

**Be sure to use the centerstand during this inspection.**

TURN MAIN SWITCH TO "ON" AND  
ENGINE STOP SWITCH TO "RUN".

TRANSMISSION IS IN GEAR AND  
SIDE STAND IS UP

PULL IN CLUTCH LEVER AND  
PUSH STARTER SWITCH.

ENGINE WILL START.

CLUTCH SWITCH IS OK.

SIDESTAND IS DOWN.

ENGINE WILL STALL.

SIDESTAND SWITCH IS OK.

EUU69100

**⚠ WARNING**

**If improper operation is noted, consult a  
Yamaha dealer immediately.**

## PRE-OPERATION CHECKS

Before using this motorcycle, check the following points:

Item	Routine	Page
Front brake	Check operation, free play, fluid level and fluid leakage. Top-up with DOT#4 (or #3) brake fluid if necessary.	6-3~6-4, 8-16~8-21
Rear brake	Check operation, condition and free play Adjust if necessary.	
Clutch	Check operation, condition and free play Adjust if necessary.	6-4, 8-22
Throttle grip/Housing	Check for smooth operation. Lubricate/Adjust if necessary.	6-4, 8-14, 8-23
Engine oil	Check oil level/add oil as required	6-4, 8-6~8-9
Final gear oil	Check for leakage visually	6-5, 8-9~8-11
Wheels/Tires	Check tire pressure, wear and damage	6-5~6-9, 8-32~8-37
Control/Meter cable	Check for smooth operation Lubricate if necessary	8-22~8-23
Brake and shift pedal shafts	Check for smooth operation. Lubricate if necessary	8-23
Brake and clutch lever pivots	Check for smooth operation Lubricate if necessary.	8-23
Center and sidestand pivots	Check for smooth operation Lubricate if necessary.	8-23~8-24
Fittings/fasteners	Check all chassis fittings and fasteners Tighten/Adjust if necessary.	6-9, 8-5

Item	Routine	Page
Fuel tank	Check fuel level/top-up as required	6-9~6-10
Lights and signals	Check for proper operation	6-9, 8-30~8-32
Battery	Check fluid level, top-up with distilled water if necessary	6-9, 8-26~8-28

**NOTE:**

Pre-operation checks should be made each time the motorcycle is used. Such an inspection can be thoroughly accomplished in a very short time, and the added safety it assures is more than worth the time involved.

** WARNING**

**If any item in the Pre-Operation Check is not working properly, have it inspected and repaired before operating the motorcycle.**

**Brakes (See page 8-16 for details)****1. Brake lever and brake pedal**

Check for correct free play in the front brake lever and rear brake pedal and adjust if necessary. Make sure the brakes are working properly by checking at low speed shortly after starting out.

EUU62300

**⚠ WARNING**

**A soft, spongy feeling in the brake lever indicates a failure in the brake system. Do not operate the motorcycle until the failure in the brake system is corrected. Ask a Yamaha dealer for immediate repairs. A soft, spongy feeling could indicate a hazardous condition in the brake system.**

**2. Brake fluid**

Check the brake fluid level. Add fluid if necessary.

**Recommended brake fluid: DOT #4**

EUU13100

**NOTE:**

If DOT #4 is not available, #3 can be used.

**3. Check the disc pads.**

Refer to page 8-19.

**4. Check the brake shoes.**

Refer to page 8-20.

EUU02201

**NOTE:**

When this brake service is necessary, consult a Yamaha dealer.

EAE11301

**Brake fluid leakage (Front)**

Apply the brake for a few minutes. Check to see if any brake fluid leaks out from the pipe joints or the master cylinder(s).

EUU37801

**CAUTION:**


**Brake fluid may deteriorate painted surfaces or plastic parts. Never spill any fluid. If spilled, clean it up immediately.**

**⚠ WARNING**

Proper loading of your motorcycle is important for several characteristics of your motorcycle; such as handling, braking, performance and safety. Do not carry loosely packed items that can shift. Securely pack your heaviest items close to the center of the motorcycle, and distribute the weight evenly from side to side. Properly adjust the suspension for your load, and check the condition and pressure of your tires. **NEVER OVERLOAD YOUR MOTORCYCLE.** Make sure the total weight of the cargo, rider, passenger, and accessories (fairing, saddlebags, etc. if approved for this model) does not exceed the maximum load of the motorcycle. Operation of an overloaded motorcycle could cause tire damage, an accident, or even injury.

## 2. Tire inspection

Always check the tires before operating the motorcycle. If a tire tread shows crosswise lines (minimum tread depth), if the tire has a nail or glass fragments in it, or if the side wall is cracked, contact a Yamaha dealer immediately and have the tire replaced.



1 Tread depth

2 Side wall

**FRONT:**

Manufacturer	Size	Type
Bridgestone	100/90-19 57H	G535
Dunlop	100/90-19 57H	F17

**REAR**

Manufacturer	Size	Type
Bridgestone	140/90-15 M/C 70H	G536
Dunlop	140/90-15 M/C 70H	K425

Minimum tire tread depth (front and rear)	1.0 mm
--	--------

EUU67900

**⚠ WARNING**

**It is dangerous to ride with a worn-out tire. When a tire tread begins to show lines, have a Yamaha dealer replace the tire immediately. Brakes, tires, and related wheel parts replacement should be left to a Yamaha Service Technician.**

EAE93800

**Tubeless tires and cast wheels**

This motorcycle is equipped with cast wheels designed for either tube-type or tubeless tires. Tubeless tires are installed as standard equipment.

EUU68600

**⚠ WARNING**

**Do not attempt to use tubeless tires on a wheel designed for use only with tube-type tires. Tire failure and personal injury may result from sudden deflation.**

Tubeless-type Wheel

→ Tubeless or Tube-type Tires

Tube Wheel

→ Tube-type Tires only

EUU68700

**⚠ WARNING**

**When using tube-type tires, be sure to install the proper tube also.**

**CAUTION:**

**Always wipe off spilled fuel immediately with a dry and clean soft cloth. Fuel may deteriorate painted surfaces or plastic parts.**

**Recommended fuel:**

Regular gasoline


For Australia:

Unleaded fuel only

Fuel tank capacity:

Total: 14.5 L

Reserve: 2.5 L



1 Filler tube

2 Fuel level

## OPERATION AND IMPORTANT RIDING POINTS

EUU67200

### **WARNING**

Before riding this motorcycle, become thoroughly familiar with all operating controls and their functions. Consult a Yamaha dealer regarding any control or function that you do not thoroughly understand.

EUU62800

### **WARNING**

1. Never start your engine or let it run for any length of time in a closed area. The exhaust fumes are poisonous and can cause loss of consciousness and death within a short time. Always operate your motorcycle in an area with adequate ventilation.

2. Before starting out, always be sure the sidestand is up. Failure to retract the sidestand completely can result in a serious accident when you try to turn a corner.
- 

EAF12801

### **Starting and warming up a cold engine**

EUU02800


#### **NOTE:**

This motorcycle is equipped with a starting and an ignition circuit cut-off switch.

1. The engine can be started only under the following conditions:
    - a. The transmission is in neutral.
    - b. The sidestand is up, the transmission is in gear, and the clutch is disengaged.
  2. The motorcycle must not be ridden when the sidestand is down.
-

**WARNING**

**Before going through the following steps, check the function of the sidestand switch and clutch switch. (Refer to page 5-15.)**



1. Turn the fuel cock to "ON".
2. Turn the main switch to "ON" and the engine stop switch to "RUN".

EUU39901

**CAUTION:** \_\_\_\_\_

**If the fuel level indicator light comes on, check the fuel level. If necessary, add fuel.**

---

3. Shift transmission into neutral.

EUU03000

**NOTE:** \_\_\_\_\_

When the transmission is in neutral, the neutral indicator light (green) should be on. If the light does not come on, ask a Yamaha dealer to inspect it.

---

4. Fully open the starter (CHOKE) and completely close the throttle grip.
5. Start the engine by pushing the starter switch.

EUU02500

**NOTE:** \_\_\_\_\_

If the engine fails to start, release the starter switch, wait a few seconds, then try again. Each attempt should be as short as possible to preserve the battery. Do not crank the engine more than 10 seconds on any one attempt.

---

EUU39800

**CAUTION:** \_\_\_\_\_

**The oil level indicator light and fuel level indicator light should come on when the starter switch is pushed and should go off when the starter switch is released. If the oil level indicator light flickers or remains on, immediately stop the engine and check the engine oil level and for oil leakage. If necessary, replenish oil and check to see that the oil level indicator light goes off. If not, consult a Yamaha dealer.**

---

6. After starting the engine, turn back the starter (CHOKE) to warming up position (about halfway).

EUU02600

**NOTE:**

For maximum engine life, always warm up the engine before starting off. Never accelerate hard with a cold engine.

7. After warming up the engine, turn off the starter completely.

EUU02700

**NOTE:**

The engine is warm when it responds normally to the throttle with the starter turned off.

EA10800

**Starting a warm engine**

The starter (CHOKE) is not required when the engine is warm.

EUU31400

**CAUTION:**

**See "Break-in section" prior to operating the motorcycle for the first time.**

EA120002

**Shifting**

The transmission lets you control the amount of power you have available at a given speed for starting, accelerating, climbing hills, etc. The use of the shift pedal is shown in the illustration. (Page 5-8)  
To shift into NEUTRAL, depress the shift pedal repeatedly until it reaches the end of its travel (you will feel a stop when you are in first gear), then raise the pedal slightly.

**CAUTION**

1. **Do not coast for long periods with the engine off, and do not tow the motorcycle a long distance. Even with gears in neutral, the transmission is only properly lubricated when the engine is running. Inadequate lubrication may damage the transmission.**
  2. **Always use the clutch when changing gears. The engine, transmission, and driveline are not designed to withstand the shock of forced shifting and can be damaged by shifting without using the clutch.**
- 

**Engine break-in**

There is never a more important period in the life of your motorcycle than the period between zero and 1,000 km. For this reason we ask that you carefully read the following material. Because the engine is brand new, you must not put an excessive load on it for the first 1,000 km. The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full throttle operation, or any condition which might result in excessive heating of the engine, must be avoided.

1. 0 ~ 150 km.

Avoid operation above 4,000 r/min. Stop the engine and let it cool for 5 to 10 minutes after every hour of operation. Vary the speed of the motorcycle from time to time. Do not operate it at one set throttle position.

2. 150 ~ 500 km:

Avoid prolonged operation above 5,000 r/min. Rev the motorcycle freely through the gears, but do not use full throttle at any time.

3. 500 ~ 1,000 km:

Avoid prolonged full throttle operation. Avoid cruising speeds in excess of 6,000 r/min.

EUU31800

**CAUTION:** \_\_\_\_\_

After 1,000 km of operation, be sure to replace the engine oil, oil filter element, and final gear oil.

---

4. 1,000 km and beyond:  
Full throttle can be used.

EUU38700

**CAUTION:** \_\_\_\_\_

Never let engine speeds enter the red zone.

---

EUU32200

**CAUTION:** \_\_\_\_\_

If any engine trouble should occur during the break-in period, consult a Yamaha dealer immediately.

---

EAF40000

**Parking**

When parking the motorcycle, stop the engine and remove the ignition key.

EUU63000

 **WARNING** \_\_\_\_\_

The muffler and exhaust pipe are hot. Park the motorcycle in a place where pedestrians or children are not likely to touch the motorcycle. Do not park the motorcycle on a slope or soft ground; the motorcycle may overturn.

---

## PERIODIC MAINTENANCE AND MINOR REPAIR

EAH00400

Periodic inspection, adjustment and lubrication will keep your motorcycle in the safest and most efficient condition possible. Safety is an obligation of the motorcycle owner. The maintenance and lubrication schedule chart should be considered strictly as a guide to general maintenance and lubrication intervals. YOU MUST TAKE INTO CONSIDERATION THAT WEATHER, TERRAIN, GEOGRAPHICAL LOCATIONS, AND A VARIETY OF INDIVIDUAL USES ALL TEND TO DEMAND THAT EACH OWNER ALTER THIS TIME SCHEDULE TO SHORTER INTERVALS TO MATCH THE ENVIRONMENT. The most important points of motorcycle inspection, adjustment, and lubrication are explained in the following pages.

EUU63200

### **WARNING**

**If you are not familiar with motorcycle service, this work should be done by a Yamaha dealer.**


EAH10101

### **Tool kit**

The service information included in this manual is intended to provide you, the owner, with the necessary information for completing some of your own preventive maintenance and minor repairs. The tools provided in the owner's tool kit are to assist you in the performance of periodic maintenance. However, some other tools such as a torque wrench are also necessary to perform the maintenance correctly.

**⚠ WARNING**

Modifications to this motorcycle not approved by Yamaha may cause loss of performance, and render it unsafe for use. Consult a Yamaha dealer before attempting any changes.



1 Open

2 Tool kit

EUU18500

**NOTE:**

If you do not have necessary tools required during a service operation, take your motorcycle to a Yamaha dealer for service.

# PERIODIC MAINTENANCE / LUBRICATION

Unit. km

Item	Remarks	BREAK-IN 1,000	EVERY	
			6,000 or 6 months	12,000 or 12 months
Valve(s)*	Check valve clearance. Adjust if necessary	○	○	○
Spark plug(s)	Check condition. Clean or replace if necessary	○	○	○
Air filter	Clean. Replace if necessary		○	○
Carburetor*	Check idle speed/synchronization/starter operation Adjust if necessary	○	○	○
Fuel line*	Check fuel hose and vacuum pipe for cracks or damage. Replace if necessary.		○	○
Engine oil	Replace (Warm engine before draining)	○	○	○
Engine oil filter*	Replace.	○		○
Final gear oil	Check oil level/oil leakage Replace every 24,000 or 24 months.	REPLACE	○	○
Front brake*	Check operation/fluid leakage/See NOTE on page 8-4. Correct if necessary		○	○
Rear brake	Check operation. Adjust if necessary.		○	○
Clutch	Check operation. Adjust if necessary		○	○
Rear arm pivot*	Check rear arm assembly for looseness. Correct if necessary. Moderately repack every 24,000 or 24 months.**			○
Wheels*	Check balance/damage/runout. Repair if necessary		○	○
Wheel bearings*	Check bearing assembly for looseness/damage Replace if damaged		○	○
Steering bearing*	Check bearings assembly for looseness Correct if necessary. Moderately repack every 24,000 or 24 months.**	○		○

Item	Remarks	BREAK-IN 1,000	EVERY	
			6,000 or 6 months	12,000 or 12 months
Front forks*	Check operation/oil leakage Repair if necessary		○	○
Rear shock absorber*	Check operation/oil leakage Repair if necessary		○	○
Fittings/Fasteners*	Check all chassis fittings and fasteners Correct if necessary	○	○	○
Center and sidestand*	Check operation Repair if necessary	○	○	○
Sidestand switch*	Check operation Clean or replace if necessary	○	○	○
Battery*	Check specific gravity Check breather pipe for proper operation Correct if necessary		○	○

\* It is recommended that these items be serviced by a Yamaha dealer

\*\* Medium weight wheel bearing grease

\*\*\* Lithium soap base grease


## NOTE:

### Brake fluid replacement:

1. When disassembling the master cylinder or caliper cylinder, replace the brake fluid. Normally check the brake fluid level and add fluid as required.
2. On the inner parts of the master cylinder and caliper cylinder, replace the oil seals every two years.
3. Replace the brake hoses every four years, or if cracked or damaged.

## Torque specifications

Use a torque wrench to tighten these items. It is recommended that these items be checked occasionally, especially before a long trip. Always check the tightness of these items whenever they are loosened for any reason.



A (Nut)	B (Bolt)	General torque specifications	
		Nm	m.kg
10 mm	6 mm	6	0.6
12 mm	8 mm	15	1.5
14 mm	10 mm	30	3.0
17 mm	12 mm	55	5.5
19 mm	14 mm	85	8.5
22 mm	16 mm	130	13.0

Item	Torque	
	Nm	m.kg
Spark plug	20	2.0
Engine oil drain plug	43	4.3
Oil filter bolt	10	1.0
Final gear oil drain plug	23	2.3
Front fork brace bolt	9	0.9
Front axle pinch bolt	20	2.0
Front wheel axle	105	10.5
Rear wheel axle nut	105	10.5
Rear axle pinch bolt	6	0.6
Tension bar bolt	20	2.0

## Engine oil

1. Oil level measurement
  - a. Place the motorcycle on the center-stand. Warm up the engine for several minutes.

EUU03901

### NOTE:


Be sure the motorcycle is positioned straight up when checking the oil level. A slight tilt toward the side can result in false readings.

- b. With the engine stopped, check the oil level through the level window located at the lower part of the left side crankcase cover.

EUU04000

### NOTE:

Wait a few minutes until the oil level settles before checking.




1 Level window

2 Maximum mark


3 Minimum mark

- c. The oil level should be between the maximum and minimum marks. If the level is low, add sufficient oil to raise it to the proper level.
2. Engine oil and oil filter replacement
  - a. Warm up the engine for a few minutes.
  - b. Stop the engine. Place an oil pan under the engine, and remove the oil filler cap.




1 Oil filler cap

c. Remove the drain plug and drain the oil.



1 Drain plug

d. Remove the oil filter bolt and filter element.




1 Oil filter cover

2 Oil filter bolt

e. Reinstall the drain plug (make sure it is tight).

Drain plug torque:  
43 Nm (4.3 m·kg)

- f. Install the new oil filter element, new O-ring(s), and the filter cover, tighten the oil filter bolt.



1 Proper O-ring position    2 Oil filter element

Oil filter bolt torque:  
10 Nm (1.0 m kg)


EUU04101

**NOTE:**

Make sure the O-ring is seated properly.

- g. Fill engine with oil. Install the oil filler cap and tighten.

**Recommended oil:**



**Oil quantity:**

Total amount:

3.6 L

Periodic oil change:

3.0 L

With oil filter replacement:

3.1 L

EUU08000

**NOTE:**

Recommended engine oil classification:  
API Service "SE", "SF" type or equivalent  
(e.g. "SF-SE", "SF-SE-CC", "SF-SE-SD"  
etc.).

**CAUTION:**

Do not put in any chemical additives. Engine oil also lubricates the clutch and additives could cause clutch slippage.

**CAUTION:**

Be sure no foreign material enters the crankcase.

- h. Start the engine and warm up for a few minutes. While warming up, check for oil leakage. If oil leakage is found, stop the engine immediately, and check for the cause.
- i. After the engine is started, the oil level indicator light should go off if oil is filled to proper level.


**CAUTION:**

If the indicator light flickers or remains on, immediately stop the engine and consult a Yamaha dealer.

**Final gear oil****! WARNING**

Do not let foreign material enter the final gear case. Be sure oil does not get on the tire or wheel.


1. Oil level measurement
  - a. Place the motorcycle on a level place, and place it on the centerstand. The engine should be cool (at ambient temperature).
  - b. Remove the oil filler cap and check the oil level. The oil level should be at the brim of the hole. Add oil as necessary.



- 1 Final gear oil  
2 Correct oil level  
3 Oil filler cap

## 2. Gear oil replacement

- Place an oil pan under the final gear case.
- Remove the final gear oil filler cap and the drain plug; drain the oil.
- Reinstall and tighten the final gear case drain plug.



- 1 Drain plug

Drain plug torque:  
23 Nm (2.3 m·kg)

- Fill the gear case to the specified level.

Oil capacity:

Final gear case:

0.2 L

Recommended oil:

SAE 80 API GL-4 Hypoid gear oil

If desired, an SAE 80W90 hypoid gear oil may be used for all conditions.

EUU02300

**NOTE:**

"GL-4" is a quality and additive rating. "GL-5" or "GL-6" rated hypoid gear oils may also be used.


- e. Reinstall the filler cap.
- f. After replacement of final gear oil, be sure to check for oil leaks.

EAH61301


**Air filter**

The air filter element should be cleaned at the specified intervals. It should be cleaned more frequently if you are riding in unusually wet or dusty areas.

1. Remove the air filter case assembly.




2. Remove the air filter case cover.



3. Remove the element.



4. Tap the element lightly to remove most of the dust and dirt and blow out the remaining dirt with compressed air from the inner surface of the element. If the element is damaged, replace it.



5. Reassemble by reversing the removal procedure.

EUU35701

**CAUTION:**

**Make sure the element is properly seated in the filter case.**

**CAUTION:**

**The engine should never be run without the air filter element installed; excessive piston and/or cylinder wear may result.**

EAH90001

**Carburetor adjustment**

The carburetor is a vital part of the engine and requires very sophisticated adjustment. Most adjustments should be left to a Yamaha dealer who has the professional knowledge and experience to do so. However, the following may be serviced by the owner as part of routine maintenance.

EUU33001


**CAUTION:**

**The carburetor was set at the Yamaha factory after many tests. If the settings are changed, poor engine performance and damage may result.**

EAH90100

**Idle speed adjustment**

1. Start the engine and warm it up for a few minutes (normally, 1 or 2 minutes) at approximately 1,000 to 2,000 r/min. Occasionally rev the engine to 4,000 to 5,000 r/min. The engine is warm when it quickly responds to the throttle.
2. Set the idle to the specified engine speed by adjusting the throttle stop screw; turn the screw in to increase engine speed, and out to decrease engine speed.



1 Throttle stop screw

Standard idle speed:  
950 ~ 1,050 r/min

EUU04500

**NOTE:**

If the specified idle speed cannot be obtained by performing the above adjustment, consult a Yamaha dealer.

EAH90301

### Throttle cable adjustment

EUU06400


**NOTE:**

Before adjusting the throttle cable free play, the engine idling speed should be adjusted.

Adjust the throttle cable by turning the adjuster so that proper free play at the throttle grip is obtained.

Free play:  
3 ~ 5 mm

1. Loosen the lock nut.
2. Turn the adjuster in or out until specified free play is obtained.
3. Tighten the lock nut.



1 Adjuster

2 Lock nut

a 3~5 mm

EAH90800

### Valve clearance adjustment

The valve clearance becomes larger with use, resulting in improper fuel/air supply and engine noise. To prevent this, the valve clearance must be adjusted regularly. This adjustment, however, should be left to a professional Yamaha service technician.


## Spark plug inspection

The spark plug is an important engine component and is easy to inspect. The condition of the spark plug can indicate the condition of the engine.

Normally, all spark plugs from the same engine should have the same color on the white porcelain insulator around the center electrode. The ideal color at this point is a medium to light tan color for a motorcycle that is being ridden normally. If one spark plug shows a distinctly different color, there could be something wrong with the engine. Do not attempt to diagnose such problems yourself. Instead, take the motorcycle to a Yamaha dealer. You should periodically remove and inspect the spark plugs because heat and deposits will cause any spark plug to slowly break down and erode. If electrode erosion becomes excessive, or if carbon and other deposits are excessive, you should replace the spark plug with the specified plug.

Standard spark plug:  
BPR7ES (NGK) or  
W22EPR-U (NIPPONDENSO)

Before installing any spark plug, measure the electrode gap with a wire thickness gauge; adjust the gap to specification.



1 Spark plug gap

Spark plug gap:  
0.7 ~ 0.8 mm

When installing the plug, always clean the gasket surface and use a new gasket. Wipe off any grime from the threads, and torque the spark plug properly.

Spark plug torque:  
20 Nm (2.0 m·kg)

EUU03801

**NOTE:**


If a torque wrench is not available when you are installing a spark plug, a good estimate of the correct torque is 1/4 to 1/2 turn past finger tight. Have the spark plug torqued to the correct value as soon as possible with a torque wrench.

EAH80100

**Front brake adjustment**

The free play at the end of the front brake lever should be 2 ~ 5 mm.

1. Loosen the lock nut.
2. Turn the adjuster so that the brake lever movement at the lever end is 2 ~ 5 mm before the adjuster contacts the master cylinder piston.
3. After adjusting, tighten the lock nut.



1 Adjuster

2 Lock nut

a 2~5 mm

**⚠ WARNING**

**Check the brake lever free play. Be sure the brake is working properly.**


**⚠ WARNING**

**A soft or spongy feeling in the brake lever can indicate the presence of air in the brake system. This air must be removed by bleeding the brake system before the motorcycle is operated. Air in the system will cause greatly diminished braking capability and can result in loss of control and an accident. Have a Yamaha dealer inspect and bleed the system if necessary.**

**Rear brake adjustment****⚠ WARNING**

**For brake pedal adjustment, be sure to proceed as follows (it is advisable to have a Yamaha dealer make this adjustment).**

1. Pedal height
  - a. Loosen the lock nut.
  - b. By turning the adjuster clockwise or counterclockwise, adjust the brake pedal position as shown.
  - c. Tighten the lock nut.



- 1 Adjuster (for pedal height)
- 2 Lock nut
- 3 Footrest
- 4 Pedal height 40 mm
- 5. Free play: 20~30 mm

EUU64400

### **⚠ WARNING**

**After adjusting the pedal height adjust brake pedal free play.**


## **2. Free play**

The rear brake pedal free play should be adjusted to 20 ~ 30 mm at the brake pedal end. Turn the adjuster on the brake rod clockwise to reduce play or counterclockwise to increase play.

EUU64500

### **⚠ WARNING**


**Check the operation of the brake light after adjusting the rear brake.**



- 1 Adjuster

## Brake light switch adjustment

The brake light switch is operated by movement of the brake pedal. To adjust, hold the main body of the switch so it does not rotate and turn the adjusting nut. Proper adjustment is achieved when the brake light comes on just before the brake begins to take effect.



1. Main body


2 Adjusting nut

## Checking the front brake pads and rear brake shoes

A wear indicator is provided on each brake. This indicator allows checking of brake pad/shoe wear without disassembling the brake.

### FRONT

Apply the brake and inspect the wear indicator. If the brake pads are worn to the wear limit, have a Yamaha dealer replace the pads.




1 Wear indicator

a Wear limit 0.5 mm

**REAR**

Apply the brake and inspect the wear indicator.

If the indicator reaches the wear limit line, ask a Yamaha dealer to replace the shoes.



1 Wear limit

2 Wear indicator

**Inspecting the brake fluid level**

Insufficient brake fluid may let air enter the brake system, possibly causing the brakes to become ineffective.

Before riding, check that the brake fluid is above the lower level and replenish when necessary.

Observe these precautions:

1. When checking the fluid level, make sure the top of the master cylinder is level by turning the handlebars.
2. Use only the designated quality brake fluid. Otherwise, the rubber seals may deteriorate, causing leakage and poor brake performance.


**Recommended brake fluid: DOT #4**

EUU13100

**NOTE:**

If DOT #4 is not available, #3 can be used.

3. Refill with the same type of brake fluid. Mixing fluids may result in a harmful chemical reaction and lead to poor brake performance.
4. Be careful that water does not enter the master cylinder when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.
5. Brake fluid may deteriorate painted surfaces or plastic parts. Always clean up spilled fluid immediately.
6. Have a Yamaha dealer check the cause if the brake fluid level goes down.



1 Lower level

EAH83501

### **Brake fluid replacement**

1. Complete fluid replacement should be done only by trained Yamaha service personnel.
2. Have a Yamaha dealer replace the following components during periodic maintenance or when they are damaged or leaking.
  - a. Replace all rubber seals every two years.
  - b. Replace all hoses every four years.

## Clutch adjustment

The clutch lever free play should be adjusted to 8 ~ 12 mm at the clutch lever. If the free play is incorrect, adjust as follows.

Free play:


8 ~ 12 mm

1. Loosen the lock nut.
2. Turn the adjuster in or out until proper lever free play is obtained.
3. Tighten the lock nut.

EUU17800

### NOTE:

If proper adjustment cannot be obtained or the clutch does not work correctly, ask a Yamaha dealer to inspect the internal clutch mechanism.



1 Lock nut

2 Adjuster

a 8~12 mm

EAI10701

## Cable inspection and lubrication

EUU64601

### ⚠ WARNING

**Damage to the outer housing of cables may allow internal rusting and cause interference with cable movement. Replace damaged cables as soon as possible to prevent unsafe conditions.**

Lubricate the inner cable and the cable end. If it does not operate smoothly, ask a Yamaha dealer to replace them.

Recommended lubricant:  
SAE 10W30 motor oil

EAI10201

### **Throttle cable and grip lubrication**

The throttle twist grip assembly should be greased at the time that the cable is lubricated, since the grip must be removed to get at the end of the throttle cable. After removing the screws, hold the end of the cable up in the air and put in several drops of lubricant. With the throttle grip disassembled, coat the metal surface of the grip assembly with a suitable all-purpose grease.

EAI30601

### **Brake and shift pedals**

Lubricate the pivoting parts.

Recommended lubricant:  
SAE 10W30 motor oil

EAI30700

### **Brake and clutch levers**

Lubricate the pivoting parts.

Recommended lubricant:  
SAE 10W30 motor oil

EAI30801

### **Center and sidestand**

Lubricate the pivoting parts. Check to see that the center and sidestand move up and down smoothly.

Recommended lubricant:  
SAE 10W30 motor oil

**⚠ WARNING**

**If the center and/or sidestand does not move smoothly, consult a Yamaha dealer.**

EAI31300

**Rear suspension**

Lubricate the pivoting parts.

Recommended lubricant:  
Lithium soap base grease

EAI20501

**Front fork inspection**

EJU65700

**⚠ WARNING**

**Securely support the motorcycle so there is no danger of it falling over.**


**1. Visual check**

Check for scratches/damage on the inner tube and excessive oil leakage from the front fork.

**2. Operation check**

Place the motorcycle on a level place.

- Hold the motorcycle in an upright position and apply the front brake.
- Stroke the front forks up and down several times.



EJU42500

**CAUTION:**


**If any damage or unsmooth movement is found with the front fork, consult a Yamaha dealer.**

## Rear shock absorber adjustment

This shock absorber is equipped with a spring preload adjuster.

Adjust spring preload as follows.

Turn adjuster in direction ① to increase spring preload and in direction ② to decrease spring preload.



A Softest

E Stiffest


EUU65200

### WARNING

**Always adjust each shock absorber to the same setting. Uneven adjustment can cause poor handling and loss of stability.**

## Steering inspection

Periodically inspect the condition of the steering. Worn out or loose steering bearings may be dangerous. Place a stand under the engine to raise the front wheel off the ground. Hold the lower end of the front forks and try to move them forward and backward. If any free play can be felt, ask a Yamaha dealer to inspect and adjust the steering. Inspection is easier if the front wheel is removed.



**⚠ WARNING**

**Securely support the motorcycle so there is no danger of it falling over.**

EAI60201

**Wheel bearings**

If there is play in the front or rear wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer inspect the wheel bearings. The wheel bearings should be inspected according to the Maintenance Schedule.

EAI70001


**Battery**

Check the level of the battery electrolyte and make sure that the terminals are tight. Add distilled water if the electrolyte level is low.

EUU33601

**CAUTION**

**When inspecting the battery, be sure the breather pipe is routed correctly. If the breather pipe is positioned in such a way as to cause battery electrolyte or gas to exit onto the frame, structural and cosmetic damage to the motorcycle can occur.**



**⚠ WARNING**

Battery electrolyte is poisonous and dangerous, causing severe burns, etc. It contains sulfuric acid. Avoid contact with skin, eyes or clothing.

Antidote:

**EXTERNAL:** Flush with water.

**INTERNAL:** Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call a physician immediately.


**EYES:** Flush with water for 15 minutes and get prompt medical attention. Batteries produce explosive gases. Keep sparks, flame, cigarettes etc., away. Ventilate when charging or using in an enclosed space. Always shield your eyes when working near batteries.

**KEEP OUT OF REACH OF CHILDREN.**

**Replenishing the battery fluid**

A poorly maintained battery will corrode and discharge quickly. The battery fluid should be checked at least once a month.

1. The level should be between the upper and lower level marks. Use only distilled water if refilling is necessary.



1. Upper level

2. Lower level


**CAUTION:**

**Normal tap water contains minerals which are harmful to a battery; therefore, refill only with distilled water.**


2. When the motorcycle will not be used for a month or longer, remove the battery and store it in a cool, dark place. Completely recharge the battery before reusing.
3. If the battery will be stored for a longer period than the above, check the specific gravity of the fluid at least once a month and recharge the battery when it is too low.
4. Always make sure the connections are correct when putting the battery back in the motorcycle. Make sure the breather pipe is properly connected and is not damaged or obstructed

**Fuse replacement**

- 1 There is a main fuse case and sub fuse block on this motorcycle. The main fuse case is located under the seat. The sub fuse block is located under the indicator lights panel.
- 2 If any fuse is blown, turn off the ignition switch and the switch of the circuit in question. Install a new fuse of proper amperage. Turn on the switches and see if the electrical device operates. If the fuse immediately blows again, consult a Yamaha dealer.



1 Main fuse



- 1 Signal
- 3 Taillight
- 5 Spare

- 2 Ignition
- 4 Headlight

### CAUTION:

Do not use fuses of higher amperage rating than those recommended. Substitution of a fuse of improper rating can cause extensive electrical system damage and possibly a fire.


#### Specified fuse:

Main:	20A
Headlight:	15A
Signal:	15A
Taillight:	10A
Ignition:	10A

## Headlight bulb replacement


This motorcycle is equipped with a quartz bulb headlight. If the headlight bulb burns out, replace the bulb as follows:

1. Remove the screws holding the light unit assembly.




1 Holding screws

2. Disconnect the headlight lead(s), remove the light unit assembly and then the cover.



1 Cover

3. Turn the bulb holder counterclockwise to remove it and remove the defective bulb.




1 Bulb holder

EUU66001

**! WARNING**

Keep flammable products and your hands away from the bulb while it is on, as it is hot. Do not touch the bulb until it cools down.

4. Put a new bulb into position and secure it in place with the bulb holder.



1. Don't touch

EUU34100

**CAUTION:**

Avoid touching the glass part of the bulb. Keep it free from oil; otherwise, the transparency of the glass, life of the bulb, and illuminous flux will be adversely affected. If oil gets on the bulb, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.

5. Install the cover.
6. Connect headlight lead(s).

7. Install the light unit assembly.  
If the headlight beam adjustment is necessary, ask a Yamaha dealer to make adjustment.

EAJ21902

## Front wheel removal

EUU66201

### WARNING


**It is advisable to have a Yamaha dealer service the wheel.**

EUU65700

### WARNING


**Securely support the motorcycle so there is no danger of it falling over.**

1. Place the motorcycle on the center-stand.
2. Remove the speedometer cable from the front wheel side.




1 Speedometer cable

3. Remove the front fork brace with fender.



4. Loosen the pinch bolt.



1 Pinch bolt

2 Wheel axle


5. Remove the wheel axle. Make sure the motorcycle is properly supported.

EUU05400

**NOTE:**

Do not depress the brake lever when the disc is off the caliper as the brake pads will be forced shut.

6. Lower the wheel until the discs come off the calipers. Turn the calipers outward so they do not obstruct the wheel, and remove the wheel.




EAJ28500


**Front wheel installation**

When installing the front wheel, reverse the removal procedure. Pay attention to the following points:

1. Make sure the wheel hub and the speedometer gear unit are installed with the projections meshed into the slots.



2. Make sure there is enough gap between the brake pads before inserting the brake disc(s).
3. Make sure the slot in the speedometer gear unit fits over the stopper on the front fork outer tube.



4. Make sure the wheel axle is properly torqued.

**Tightening torque:**  
**105 Nm (10.5 m·kg)**

5. Before tightening the pinch bolt, stroke the front fork several times to check for proper fork operation.

6. Tighten the pinch bolt.

Tightening torque:  
20 Nm (2.0 m·kg)

7. Tighten the front fork brace bolts.

Tightening torque:  
9 Nm (0.9 m·kg)

EAJ65100

### Rear wheel removal

EUU66201

#### **⚠ WARNING**

It is advisable to have a Yamaha dealer service the wheel.


EUU65700

#### **⚠ WARNING**


Securely support the motorcycle so there is no danger of it falling over.

1. Place the motorcycle on the center-stand.


2. Remove the tension bar and the brake rod from the rear wheel side. The tension bar can be removed by removing the cotter pin and nut from the tension bar bolt. The brake rod can be removed by removing the adjuster.



1. Adjuster      2. Tension bar      3. Brake rod
3. Remove the muffler installation bolt(s).




4. Remove the axle nut cotter pin and the axle nut.



1 Cotter pin

2 Axle nut

5. Loosen the rear axle pinch bolt. While pulling up the muffler slightly, pull out the rear axle.




1 Pinch bolt

6. Move the wheel to the right to separate it from the final gear case and remove the rear wheel.

## Rear wheel installation

When installing the rear wheel, reverse the removal procedure. Pay attention to the following points:

1. Apply a light coating of lithium base grease to final gear case splines and rear wheel hub splines.
2. Make sure the splines on the wheel hub fit into the final gear case.



3. Make sure the following parts are properly torqued, and a new cotter pin is installed.



## WARNING

**Always use a new cotter pin.**

Tightening torque:

Axle nut:

105 Nm (10.5 m·kg)

Tension bar bolt:

6 Nm (0.6 m·kg)

Pinch bolt:

20 Nm (2.0 m·kg)

4. Adjust the rear brake. (See page 8-17)



## WARNING

**Check the operation of the brake light after adjusting the rear brake.**

## **Troubleshooting**

Although Yamaha motorcycles receive a rigid inspection before shipment from the factory, trouble may occur during operation.


Any problem in the fuel, compression, or ignition systems can cause poor starting and loss of power. The troubleshooting chart describes a quick, easy procedure for making checks.

If your motorcycle requires any repair, bring it to a Yamaha dealer. The skilled technicians at a Yamaha dealership have the tools, experience, and know-how to properly service your motorcycle. Use only genuine Yamaha parts on your motorcycle. Imitation parts may look like Yamaha parts, but they are often inferior. Consequently, they have a shorter service life and can lead to expensive repair bills.

# Troubleshooting chart

## ⚠ WARNING

Never check the fuel system while smoking or in the vicinity of an open flame.



## **CLEANING AND STORAGE**

EAK01102

### **A. CLEANING**

Frequent, thorough cleaning of your motorcycle will not only enhance its appearance but will improve its general performance and extend the useful life of many components.

1. Before cleaning the motorcycle:
  - a. Block off the end of the exhaust pipe to prevent water entry; a plastic bag and strong rubber band may be used.
  - b. Make sure the spark plug(s) and all filler caps are properly installed.
2. If the engine case is excessively greasy, apply degreaser with a paint brush. Do not apply degreaser to wheel axles.
3. Rinse the dirt and degreaser off with a garden hose. Use only enough pressure to do the job.

### **CAUTION:**

---

**Excessive hose pressure may cause water seepage and deterioration of wheel bearings, front fork, brakes, transmission seals and electrical parts.**

**Many expensive repair bills have resulted from improper high pressure detergent applications such as those available in coin-operated car washers.**

---

4. Once the majority of the dirt has been hosed off, wash all surfaces with warm water and mild, detergent-type soap. An old toothbrush or bottle brush is handy for hard-to-get-at places.
5. Rinse the motorcycle off immediately with clean water and dry all surfaces with a chamois, clean towel, or soft absorbent cloth.

6. Clean the seat with a vinyl upholstery cleaner to keep the cover pliable and glossy.
7. Automotive-type wax may be applied to all painted and chrome-plated surfaces. Avoid combination cleaner-waxes. Many contain abrasives which may mar the paint or protective finish. When finished, start the engine and let it idle for several minutes.

EAK00400

## **B. STORAGE**

Long term storage (60 days or more) of your motorcycle will require some preventive procedures to guard against deterioration. After thoroughly cleaning the motorcycle, prepare for storage as follows:

1. Drain the fuel tank, fuel lines, and carburetor float bowl(s).

2. Remove the empty fuel tank, pour a cup of SAE 10W30 or 20W40 motor oil in the tank, shake the tank to coat the inner surfaces thoroughly and drain off the excess oil. Reinstall the tank.
3. Remove the spark plug, pour about one tablespoon of SAE 10W30 or 20W40 motor oil in the spark plug hole and reinstall the spark plug. Turn the engine over several times (ground spark plug lead wires) to coat the cylinder walls with oil.

EUU66400

### **WARNING**

**When using the starter motor to crank the engine, remove the spark plug wires, and ground them to prevent sparking.**

4. Lubricate all control cables.
5. Block up the frame to raise both wheels off the ground.

6. Tie a plastic bag over the exhaust pipe outlet to prevent moisture from entering.
7. If storing in a humid or salt-air atmosphere, coat all exposed metal surfaces with a light film of oil. Do not apply oil to any rubber parts or the seat cover.
8. Remove the battery and charge it. Store it in a dry place and recharge it once a month. Do not store the battery in an excessively warm or cold place (less than 0°C or more than 30°C).

EUU05800


**NOTE:** \_\_\_\_\_

**Make any necessary repairs before storing the motorcycle.**

---

# SPECIFICATIONS

Model	XV750G
<b>Dimension:</b> Overall length Overall width Overall height Seat height Wheel base Minimum ground clearance	2,285 mm 840 mm 1,190 mm 715 mm 1,525 mm 145 mm
<b>Basic weight:</b> With oil and full fuel tank	235 kg
<b>Minimum turning radius:</b>	2,800 mm
<b>Engine:</b> Type Model Cylinder arrangement Displacement Bore × Stroke Compression ratio Starting system Lubrication system	Air cooled, 4-stroke, gasoline, SOHC 4PV1 V-2 cylinder 749 cm <sup>3</sup> 83.0 × 69.2 mm 8.7 : 1 Electric starter Wet sump

Model	XV750G
<p>Engine oil (4-cycle) Type</p>  <p>Capacity Periodic oil change With oil filter replacement Total amount</p>	<p>SAE 20W40 type SE motor oil (If temperature does not go below 5°C)</p> <p>SAE 10W30 type SE motor oil (If temperature does not go above 15°C)</p> <p>3.0 L 3.1 L 3.6 L</p>
<p>Final gear oil: Type Capacity</p>	<p>SAE 80 API "GL-4" Hypoid gear oil 0.2 L</p>
<p>Air filter:</p>	<p>Dry type element</p>
<p>Fuel: Type</p> <p>Tank capacity Reserve amount</p>	<p>Regular gasoline For Australia: Unleaded fuel only</p> <p>14.5 L 2.5 L</p>
<p>Carburetor: Type/manufacture</p>	<p>BST40/MIKUNI</p>
<p>Spark plug: Type/manufacture Gap</p>	<p>BPR7ES/NGK or W22EPR-U/NIPPONDENSO 0.7 ~ 0.8 mm</p>

Model	XV750G
Clutch type	Wet, multi-disc
Transmission Primary reduction system Primary reduction ratio Secondary reduction system Secondary reduction ratio Transmission type Operation Gear ratio 1st 2nd 3rd 4th 5th	Spur gear 78/47 (1.659) Shaft drive 47/45 × 19/18 × 32/11 (3.207) Constant mesh 5-speed Left foot operation  40/17 (2.352) 40/24 (1.666) 36/28 (1.285) 32/31 (1.032) 29/34 (0.852)
Chassis: Frame type Caster angle Trail	Pressed backbone 32° 129 mm
Tire Type Size – Front Rear	Tubeless tire 100/90-19 57H 140/90-15 M/C 70H
Brake Front brake type Operation Rear brake type Operation	Dual, Disc brake Right hand operation Drum brake Right foot operation

Model	XV750G
Suspension Front Rear	Telescopic fork Swingarm
Shock absorber: Front Rear	Coil spring, Oil damper Coil spring, Oil damper
Wheel travel Front Rear	150 mm 97 mm
Electrical Ignition system Generator system Battery type/capacity	TCI (Digital) AC magneto generator YB16AL/12V 16AH
Headlight type	Quartz bulb
Bulb wattage/quantity: Headlight Tail/brake light Flasher light Meter light	12V 60W/55W × 1 12V 5W/21W × 2 12V 21W × 4 12V 3W × 4
Indicator light wattage/quantity "NEUTRAL" "HIGH BEAM" "OIL LEVEL" "TURN" "FUEL LEVEL"	12V 3W × 1 12V 3W × 1 12V 3W × 1 12V 3W × 2 12V 3W × 1

## HOW TO USE THE CONVERSION TABLE

All specification data in this manual is listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMP unit data.

Ex.

METRIC		MULTIPLIER		IMP
**mm	×	0.03937	=	**in
2 mm	×	0.03937	=	0.08 in

## CONVERSION TABLE

METRIC TO IMP			
	Known	Multiplier	Result
Torque	m kg	7.233	ft lb
	m·kg	86 794	in·lb
	cm kg	0 0723	ft lb
	cm·kg	0 8679	in lb
Wt.	kg	2.205	lb
	g	0.03527	oz
Distance	km/hr	0.6214	mph
	km	0.6214	mi
	m	3 281	ft
	m	1 094	yd
	cm	0.3937	in
	mm	0.03937	in
Vol / Capacity	cc(cm <sup>3</sup> )	0.03527	oz (IMP liq.)
	cc(cm <sup>3</sup> )	0 06102	cu.in
	lit (liter)	0 8799	qt (IMP liq.)
	lit (liter)	0 2199	gal (IMP liq.)
Misc	kg/mm	55 997	lb/in
	kg/cm <sup>2</sup>	14 2234	psi (lb/in <sup>2</sup> )
	Centigrade	9/5(°C)+32	Fahrenheit (°F)

## **NOISE REGULATION (FOR Australia)**

### **"TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED"**

Owners are warned that the law may prohibit:

- (a) The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; and
- (b) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.


**YAMAHA MOTOR CO.,LTD.**

PRINTED ON RECYCLED PAPER

PRINTED IN JAPAN  
94 7-0.3 x 1 CR  
(英)



# WIRING DIAGRAM XV750



## COLOR CODE

B. . . . . Black	P. . . . . Pink	W. . . . . White	L/W. . . . . Blue/White	Br/W. . . . . Brown/White
L. . . . . Blue	Br. . . . . Brown	B/Y. . . . . Black/Yellow	G/Y. . . . . Green/Yellow	W/G. . . . . White/Green
G. . . . . Green	Ch. . . . . Chocolate	B/R. . . . . Black/Red	Y/R. . . . . Yellow/Red	
Y. . . . . Yellow	Gy. . . . . Gray	BW. . . . . Black/White	R/B. . . . . Red/Black	
R. . . . . Red	Sb. . . . . Sky blue	L/B. . . . . Blue/Black	R/Y. . . . . Red/Yellow	
O. . . . . Orange	Dg. . . . . Dark green	L/Y. . . . . Blue/Yellow	R/W. . . . . Red/White	

- 1 A C magneto
- 2 Neutral switch
- 3 Rectifier/regulator
- 4 Main switch
- 5 Fuse (Main)
- 6 Starter relay
- 7 Battery
- 8 Solenoid
- 9 Starter motor
- 10 Diode assembly
- 11 Clutch switch
- 12 Igniter unit
- 13 Sidestand switch
- 14 Ignition coil
- 15 Spark plug
- 16 Pick-up coil
- 17 Meter assembly
- 18 "NEUTRAL" indicator light
- 19 "OIL LEVEL" indicator light
- 20 "FUEL LEVEL" indicator light
- 21 Tachometer
- 22 Reed switch
- 23 Meter light
- 24 "HIGH BEAM" indicator light
- 25 "TURN" indicator light (Left)
- 26 "TURN" indicator light (Right)
- 27 Fuel sender
- 28 Diode
- 29 Flasher relay
- 30 Oil level gauge
- 31 Handlebar switch (Right)
- 32 "ENGINE STOP" switch
- 33 "START" switch
- 34 Horn
- 35 Front brake switch
- 36 Rear brake switch
- 37 Handlebar switch (Left)
- 38 "PASS" switch
- 39 "LIGHTS" (Dimmer) switch
- 40 "TURN" signal switch
- 41 "HORN" switch
- 42 Headlight
- 43 Tail/brake light
- 44 Front flasher light
- 45 Rear flasher light